

ONE LOOP TOUCH SCREEN ANALOGUE ADDRESSABLE FIRE ALARM PANEL



SMART CONNECT INSTALLATION MANUAL

MANUAL SECTIONS

1- SAFETY INFORMATION	3
2- PANEL SPECIFICATION	6
3-INTRODUCTION TO THE SMART CONNECT PANEL.....	10
4 - DESIGNING THE SYSTEM	19
5 - INSTALLING THE PANEL	24
6 - INSTALLING THE DEVICES.....	28
7 - PANEL SET UP	41
8 - PROGRAMMING	48
9 - DISABLEMENTS.....	64
10 - TEST MODE	72
11 - NETWORKING	75
12 - FAULT FINDING.....	79
13 - STANDBY BATTERY REQUIREMENTS	87
14 - CE INFORMATION.....	91
15 - DOCUMENT MODIFICATION HISTORY.....	92

1- SAFETY INFORMATION

1.1 INSTALLATION INFORMATION.....	4
1.2 SAFETY PRECAUTIONS DURING NORMAL OPERATION OF PANEL	4
1.3 BATTERY INFORMATION.....	4
1.4 PRODUCT DISPOSAL AT THE END OF ITS WORKING LIFE	4
1.5 USING THIS MANUAL.....	5
1.6 FIRE ALARM SYSTEMS CODE OF PRACTICE.....	5
1.7 EQUIPMENT WARRANTY	5

Smart Connect Single Loop Touch Screen Panel

WARNING: Read this section completely before commencing installation.

1.1 INSTALLATION INFORMATION

THIS FIRE ALARM CONTROL PANEL IS CLASS1 EQUIPMENT AND MUST BE EARTHED.

This equipment must be installed and maintained by a qualified and technically experienced person.

This C.I.E. must be wired to a fused spur rated at 3A. It must NOT be connected via a removable plug, or be connected through an RCD device.

It is designed for indoor use only.

Prior to commencing installation of the control panel, ensure that adequate precautions are taken to prevent damage to the sensitive electronic components on the display board and the control board due to electrostatic discharge. You should discharge any static electricity you may have accumulated by touching a convenient earthed object such as an unpainted copper radiator pipe. You should repeat the process at regular intervals during the installation process, especially if you are required to walk over carpets.

The panel must be located in a clean, dry position, which is not subject to excessive shock or vibration and at least 2 metres away from pager systems or any other radio transmitting equipment. The operating temperature range is 0°C to 40°C; maximum humidity is 95%.

HANDLING THE PCBs

If the PCBs are to be removed to ease fitting the enclosure and cables, care must be taken to avoid damage by static.

The best method is to wear an earth strap, but touching any earth point (e.g. building plumbing) will help to discharge any static. Always handle PCBs by their sides and avoid touching the legs of any components. Keep the PCBs away from damp dirty areas, e.g. in a small cardboard box.

1.2 SAFETY PRECAUTIONS DURING NORMAL OPERATION OF PANEL

NOTE: When the Smart Connect panel is operating normally, i.e. not being tended by service personnel, the panel enclosure must be kept closed, secured by the supplied hex screws. The hex key to open the cover MUST be removed and ONLY held by the responsible person and / or the service personnel. It must under NO CIRCUMSTANCES be held by the user.

1.3 BATTERY INFORMATION

This C.I.E. uses 2 x 12V Sealed Lead Acid (SLA) batteries with capacities between 3Ah and 7Ah.

CAUTION:

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO BATTERY MANUFACTURERS INSTRUCTIONS.

IMPORTANT NOTES ON BATTERIES:

DANGER: Batteries are electrically live at all times. **NEVER short circuit the battery terminals.**

WARNING: Batteries are often heavy. Each 17Ah battery weighs 6.1kg. Take great care when lifting and transporting batteries.

DANGER: Do NOT attempt to remove the battery lid or tamper with the internal workings of the battery. Electrolyte is a highly corrosive substance, and presents significant danger to yourself and to anything else it touches. In case of accidental skin or eye contact, flush the affected area with plenty of clean, fresh water and seek immediate medical attention. Valve Regulated Lead Acid (VRLA) batteries are "low maintenance", requiring no electrolyte top-up or measurement of specific gravity.

1.4 PRODUCT DISPOSAL AT THE END OF ITS WORKING LIFE

Like all electronic equipment, at the end of its working life this unit should not be disposed of in a refuse bin. It should be taken to a local reprocessing site as per the guidelines of the WEEE directive, for correct disposal.

1.5 USING THIS MANUAL

This manual explains, in a step-by-step manner, the procedure for the installation of the Smart Connect Fire Alarm Control Panel. This Installation Manual must not be left accessible to the User.

1.6 FIRE ALARM SYSTEMS CODE OF PRACTICE

This manual is not designed to teach Fire Alarm System design. It is assumed that the System has been designed by a competent person, and that the installer has an understanding of Fire Alarm System components and their use.

We strongly recommend consultation with a suitably qualified, competent person regarding the design of the Fire Alarm System. The System must be commissioned and serviced in accordance with our instructions and the relevant National Standards. Contact the Fire Officer concerned with the property at an early stage in case he has any special requirements.

If in doubt, read the latest edition of BS 5839-1 "Fire Detection and Alarm Systems for buildings (Code of Practice for System Design, Installation, commissioning and maintenance)" available from the BSI, or at your local reference library.

1.7 EQUIPMENT WARRANTY

If this equipment is not fitted and commissioned according to our guidelines, and the relevant National Standards, by an approved and competent person or organisation, the warranty may become void.

2- PANEL SPECIFICATION

2.1 FUNCTIONS REQUIRED BY EUROPEAN STANDARD EN 54 PART 2	7
2.2 EXPLANATION OF ACCESS LEVELS	7
2.3 PANEL SPECIFICATIONS - ENCLOSURE	8
2.4 PANEL SPECIFICATIONS - ELECTRICAL	8
2.5 FUSE SPECIFICATIONS - Power Supply Controller PCB	9
2.6 FUSE SPECIFICATIONS - <i>CIE PCB</i>	9

2.1 FUNCTIONS REQUIRED BY EUROPEAN STANDARD EN 54 PART 2

The Smart Connect fire alarm control panel provides the following mandatory and optional functions as prescribed by the European standard EN 54 Part 2.

(a) Mandatory Functions

The mandatory functions and corresponding indications provided by this panel are:

- fire alarm condition
- fault warning condition
- disablement condition
- quiescent condition (when the CIE is powered by a power supply conforming to EN 54-4 and no other functional condition is indicated)

(b) Optional Functions (Options with Requirements)

The options with requirements provided by this panel are:

- Clause 7.8 - output to fire alarm devices (i.e. sounders)
- Clause 7.11 - delays to outputs
- Clause 7.12 – Dependencies on More than one alarm signal (Type C)
- Clause 8.3 - fault signals from points
- Clause 9.5 - disablement of addressable points
- Clause 10 – test Condition

(c) Other Functions outside EN54

USB Port (For PC configuration)
RS484 Network / Repeater connection
TCP/IP (Ethernet) connection (Remote access)

WARNING: DO NOT PLUG SMART CONNECT INTO PoE ETHERNET SOCKET. THIS WILL DAMAGE THE PANEL.

NB the terms 'device' and 'point' are used interchangeably throughout this manual.

EN54-2 Requires that in the event of a system fault, no more than 512 Fire detectors, and/or Manual Call points should be affected. It is not possible to exceed this number using addressable detectors, but care should be taken not to exceed 512 Detectors/Call points if conventional devices are fitted to Zone Monitor modules.

2.2 EXPLANATION OF ACCESS LEVELS

The Smart Connect System has the following access levels.

ACCESS LEVEL	ACCESSED BY	ACCESS METHOD	FUNCTIONS ACCESSED
1	General public	Default state	View Panel Override delay (if used)
2a	Responsible person	Enter user access code (default 0001)	Start sounders stop sounders Silence buzzer Reset panel Access User Menu
2b	Responsible person	Enter user access code (default 0001), and press Menu Access Icon	Enable / disable sections of system Test Mode View Zones / Points View event log Turn off delay
3a	Installer / Engineer	Enter Engineer Password (Default 9999), and press Menu Access Icon	Configure loops Assign zones Assign Text to each point Modify Alarm Operation Programming Configure network (if fitted) System Diagnostics (LED blink / loop Autocheck) Change passwords Configure TCP/IP Port
3b	Installer / Engineer	Open Enclosure	Connect wiring during Install Battery check during Maintenance Update Cause & Effect programming via USB
4	Authorised Service Engineer	Open Enclosure & PC S/W	Update Panel Firmware, Add new language

Care should be taken to ensure that the access method for each level is only available to suitably qualified personnel.


2.3 PANEL SPECIFICATIONS - ENCLOSURE

DESCRIPTION	VALUE
ENCLOSURE SIZE (L x W x D mm)	370 X 311 X 113 mm
TOP CABLE ENTRIES	15
BOTTOM CABLE ENTRIES	0

2.4 PANEL SPECIFICATIONS - ELECTRICAL

ELECTRICAL DESCRIPTION	VALUE
MAINS VOLTAGE	230 V AC + 10% / - 15%
BATTERY VOLTAGE	2 x 12V SLA (27.6V DC @ 20 C) (3Ah – 7Ah)
POWER SUPPLY	NON-INTEGRAL (SWITCH MODE) DC OUTPUT: Vmax = 31V ,Vmin = 19.5V I max A: 1.4 A I max B: 1.4 A I min: 150 mA Ri max: 2 Ohms Ripple & Noise: <= 0.6V
MAXIMUM CURRENT DRAWN FROM THE BATTERY BY THE PSE WHEN THE MAIN POWER SOURCE IS DISCONNECTED	25mA
CIE DC INPUT VOLTAGE	Vmax = 31.5V, Vmin = 19.5V
CHARGER VOLTAGE	27.3V
Monitored Inputs (x2)	End-of-Line Resistance: 4k7ohm 0.25W Trigger value: 2k7 ohm
CONVENTIONAL SOUNDER OUTPUT (x2)	I max: 100mA Quiescent voltage: -5 to -9V DC Active voltage: 18 to 28V DC End-of-Line Resistance: 4k7 ohm 0.25W
FIRE RELAY OUTPUT (x1)	(C,NO,NC) Contact rating: 230V AC @ 1A
FAULT RELAY OUTPUT (x1)	Normally Energised (C,NO,NC) Contact rating: 230V AC @ 1A
AUX 28V OUTPUT: VOLTAGE RANGE	18V to 30V DC
AUX 28V OUTPUT: CURRENT RATING	100mA
LOOP VOLTAGE	35V Nominal (Vmax 39 V DC Vmin 24 V DC)
MAXIMUM LOOP CURRENT	500 mA
NUMBER OF LOOPS	1
MAXIMUM NUMBER OF ZONES	254 Zones
MAXIMUM LOOP CAPACITY	250 Addresses
MAXIMUM LOOP LENGTH	2 km
MAXIMUM LOOP RESISTANCE	44 ohm (22 ohms + to +, 22 ohms – to -)
MAXIMUM LOOP CAPACITANCE	500 nF
MAXIMUM LOOP BAUD RATE	1024 Bits Per Second
MAXIMUM NETWORK SIZE	64 nodes
MAXIMUM DISTANCE BETWEEN NODES	1 km with screened Data cable
LCD DISPLAY	4.3" Resistive touch screen. 480 x 272 pixel resolution
LED INDICATION	Fire Zones 1 – 16 Fault / Disable / Test Zones 1 - 16 Power Common Fire Sounder Delay On General Disablement Controls active System Fault Common Fault Sounder Fault / Disablement General Test Sounder Active
KEY ENTRY	Start Sounders Stop Sounders Silence Buzzer Reset (All other controls via touch screen)
ENVIRONMENTAL DATA	Temperature: -5 to 40 C Relative Humidity: 95% Non-Condensing will withstand vibrations between 5 & 150 Hz
ENCLOSURE RATING	IP 30
OTHER PORTS	USB RS485 for network TCP/IP Micro SD card (for future use)
EN 54-2 Optional Functions with Requirements	7.8, 7.11,7.12, 8.3, 9.5, 10

2.5 FUSE SPECIFICATIONS - Power Supply Controller PCB



Fuse Label	Rating	Description
A_Fuse	1A	PSU Output – Channel A (USED TO POWER PANEL)
B_Fuse	1A	PSU Output – Channel B (SPARE)
Battery Fuse	5A	Battery fuse


2.6 FUSE SPECIFICATIONS - CIE PCB

The Smart Connect CIE PCB has no User serviceable fuses. It uses resettable fuses throughout

3-INTRODUCTION TO THE SMART CONNECT PANEL

3.1 ABOUT THE SMART CONNECT FIRE ALARM PANEL.....	11
3.2 PANEL INTERNAL LAYOUT	12
3.3 ACCESSING THE PANEL	13
3.4 NAVIGATING THE PANEL MENUS	14
3.5 CONTROLS	15
3.6 INDICATING DIFFERENT PANEL STATES.....	16
3.6.1 The Quiescent Condition	16
3.6.2 The Alarm Condition.....	16
3.6.3 The Fault Condition	16
3.6.4. Disablement	17
3.6.5 Test Mode.....	18
3.6.6 Multiple Conditions.....	18

3.1 ABOUT THE SMART CONNECT FIRE ALARM PANEL



- The Smart Connect is a fully featured single loop addressable fire alarm panel.
- 4.3 inch colour touch screen display.
- Easy to use configuration software
- It can run 250 MKII protocol devices per loop.
- 2 x configurable RS485 ports
- Up to 8 password protected users
- It has 250 zones, with 16 zones indicated by LED
- It can be networked with other Smart Connect panels with up to 16 panels per network.
- It has a simple Intuitive cause and effect programming for configuring sounder & relay operation.
- It has a built in TCP-IP port that allows remote access to the panel for authorised service companies.
- Meets all requirements of latest EN54 part2 and part4.

3.2 PANEL INTERNAL LAYOUT





Figure1






Figure1: Plan view of Smart Connect panel showing internal view with main PCB fitted and with main PCB removed

3.3 ACCESSING THE PANEL


The Smart Connect panel has 2 user access levels and one installer access level.

<p>Basic user access (Access level 2a)</p> <p>Tap LCD. Select user icon . Enter user access code (Default 0001) This allows the user to have access to the main control buttons, to silence and reset the panel. It is indicated by a steady Controls Active LED, and an open padlock icon in the bottom left corner of the LCD screen.</p>	
<p>Full user access (Access level 2b)</p> <p>From access level 2a press the menu access icon.</p> <p>This allows the user to view the user menus, to view device status, event logs etc. It is indicated by a steady Controls Active LED, and an open padlock icon in the bottom left corner of the LCD screen.</p>	
<p>Engineer Access (Access level 3a)</p> <p>Tap LCD. Select Engineer icon . Enter Engineer access code (Default 9999) This allows the engineer to configure the panel, Setting zone & device text, allocating zones, entering panel cause & effect etc. It is indicated by a Flasing Controls Active LED, and an open padlock icon in the bottom left corner of the LCD screen. (The access LED flashes as a reminder that the panel is at a high access level, and should not be left unattended in this state.)</p>	
<p>Turning off access.</p> <p>If the panel is in one of the menus, press the exit menu icon  in the bottom left corner.</p> <p>Press the padlock icon  in the bottom left corner. The controls active LCD will turn off, and the padlock icon will turn off.</p> <p>(The panel will automatically turn off access if left unattended for approx 5 minutes)</p>	

3.4 NAVIGATING THE PANEL MENUS

<p>The Smart Connect panel has 2 menus, user and installer. Entering the user code (Default 0001) accesses the user menu. Entering the Installer password (Default 9999) enables access level 3. Press the access menu icon  to access the Engineer menu</p>																										
<p>The menus are in the form of icons with a text label underneath. To select a particular menu, press the relevant icon.</p> <p>The sub screens are in the form of tabbed screens if there is more than one sub - option, with the data either displayed in a table, or as separate data fields, depending on the function of the sub screen</p>																										
<p>Table view screen Example</p> <p>In a table field, there are editable data (eg device label), and non-editable data (eg Device type). Tapping on an editable data field will allow it to be edited.</p>	 <table border="1" data-bbox="917 952 1417 1086"> <thead> <tr> <th>Addr</th> <th>Type</th> <th>Point text</th> <th>Mode</th> <th>Zn/Ag</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>MCP ADDR</td> <td>MAIN ENTRANCE</td> <td>Enabled</td> <td>1</td> </tr> <tr> <td>2</td> <td>INPUT MOD</td> <td>RECEPTION</td> <td>Enabled</td> <td>1</td> </tr> <tr> <td>3</td> <td>HEAT CS</td> <td>ADMIN</td> <td>Enabled</td> <td>1</td> </tr> <tr> <td>4</td> <td>HEAT CS</td> <td>CANTEEN</td> <td>Enabled</td> <td>1</td> </tr> </tbody> </table>	Addr	Type	Point text	Mode	Zn/Ag	1	MCP ADDR	MAIN ENTRANCE	Enabled	1	2	INPUT MOD	RECEPTION	Enabled	1	3	HEAT CS	ADMIN	Enabled	1	4	HEAT CS	CANTEEN	Enabled	1
Addr	Type	Point text	Mode	Zn/Ag																						
1	MCP ADDR	MAIN ENTRANCE	Enabled	1																						
2	INPUT MOD	RECEPTION	Enabled	1																						
3	HEAT CS	ADMIN	Enabled	1																						
4	HEAT CS	CANTEEN	Enabled	1																						
<p>Data Field Screen Example</p> <p>In a data field screen, the data will either be values, or option buttons. Clicking on the field will allow it to be edited.</p>																										
<p>Text Keyboard</p> <p>Used to enter text. Use <- and -> to position the keyboard. Press the circle at the end of the text field to delete text as required. 123 will bring up the numeric keyboard. And CAP turns on the caps lock.</p> <p>Press tick when finished.</p>																										
<p>Number Keyboard.</p> <p>Use the up & down Icons to increase or decrease the number, or enter the new number via the keypad.</p>																										

3.5 CONTROLS



The panel contains the following mandatory controls. They can only be operated when the user or engineer (ADMIN) password has been entered. The CONTROLS ACTIVE LED indicates that the controls have been enabled.

- This control  can be used by authorised personnel to start the sounders.
- This control  can be used by authorised personnel to stop or silence the sounders whilst the panel is in the fire alarm condition.
- This control  silences the panel's internal buzzer which is always activated when a fire or a fault has been detected.
- After an alarm has been fully investigated and dealt with, operating this control  resets the fire alarm condition. The same control is used to reset from a fault condition.

It is good practice to stop the sounders before resetting the panel. However, pressing the RESET control whilst the sounders are still active will silence the sounders as well as resetting the fire alarm condition.

OTHER CONTROLS

Other controls are through virtual buttons on the panel's touch screen display. They include, amongst others, alpha and numeric key pads, cursors for table navigation and accept & cancel buttons for system changes


3.6 INDICATING DIFFERENT PANEL STATES

During Normal operation the panel will be in one of the following states depending on the status of the devices connected to the panel, and user intervention. Below is a summary of the different conditions


3.6.1 The Quiescent Condition

<p>This is the panel's normal state. There are no faults or alarms, and the panel is running normally. This is indicated by The LCD showing System Normal, and All LEDs being off, apart from Power, and perhaps Controls Active (depending on the last user action).</p> <p>In the quiescent condition, the panel displays:- System Healthy. Zeta Logo</p>	
---	--




3.6.2 The Alarm Condition

<p>A fire is indicated on the Smart Connect panel by:-</p> <p>COMMON FIRE RED LED & Zone alarm LED (for zones 1 to 16)</p> <p>On the screen, the panel shows:-</p> <p>Fire Icon Number of zones in alarm Number of devices in alarm First & last zones in alarm Details of alarms in chronological order (showing device type, Zone number & label, Device address & label) Scroll arrows for displaying further events</p>	
---	---



3.6.3 The Fault Condition

<p>All faults are indicated by a flashing yellow common fault LED, and either an additional fault LED, or an LCD message.</p> <p>Faults can be divided into 2 types, "Device Faults" and "General Faults". Device Faults are any fault associated with a particular device address on the loop. They usually report Address & zone information as well as a description of the fault.</p>	
<p>General Faults are everything else, e.g. sounder circuits, power supply, earth faults etc. Any fault on the panel will flash the common fault LED in addition to displaying details of the fault.</p>	

3.6.4. Disablement

<p>Disablements are indicated with the general disablement LED, and a mixture of LCD/LED indications</p> <p>In this example, zone 1 is disabled. The panel shows that one zone is disabled, and that the 13 devices in that zone are disabled. Press the zone icon, or the Device icon for details of the disablements.</p>																													
<p>In this example, there is a single addressable point disabled. Press the Device icon for details of the disablement</p>																													
<p>In this example, sounder circuit 1 on the motherboard has been disabled</p>																													
<p>Pressing one of the zone disablement icons will give further details about the disablement.</p>	 <table border="1" data-bbox="868 1429 1385 1599"> <thead> <tr> <th>Text</th> <th>In</th> </tr> </thead> <tbody> <tr> <td>2 Ground Level</td> <td>Disabled</td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> </tr> </tbody> </table>	Text	In	2 Ground Level	Disabled																								
Text	In																												
2 Ground Level	Disabled																												
<p>Or pressing the disabled loop devices icon will give details of the devices disabled.</p>	 <table border="1" data-bbox="868 1787 1385 1957"> <thead> <tr> <th>Address</th> <th>Type</th> <th>Point text</th> <th>Mode</th> </tr> </thead> <tbody> <tr> <td>12</td> <td>MCP ADDR</td> <td>Main Entrance</td> <td>Disabled</td> </tr> <tr> <td>13</td> <td>INPUT MOD</td> <td>Reception</td> <td>Disabled</td> </tr> <tr> <td>14</td> <td>HEAT CS</td> <td>ADMIN AREA</td> <td>Disabled</td> </tr> <tr> <td>15</td> <td>HEAT CS</td> <td>OFFICE</td> <td>Disabled</td> </tr> <tr> <td>16</td> <td>HEAT CS</td> <td>OFFICE 2</td> <td>Disabled</td> </tr> <tr> <td>17</td> <td>OPT STAND</td> <td>Stock Room</td> <td>Disabled</td> </tr> </tbody> </table>	Address	Type	Point text	Mode	12	MCP ADDR	Main Entrance	Disabled	13	INPUT MOD	Reception	Disabled	14	HEAT CS	ADMIN AREA	Disabled	15	HEAT CS	OFFICE	Disabled	16	HEAT CS	OFFICE 2	Disabled	17	OPT STAND	Stock Room	Disabled
Address	Type	Point text	Mode																										
12	MCP ADDR	Main Entrance	Disabled																										
13	INPUT MOD	Reception	Disabled																										
14	HEAT CS	ADMIN AREA	Disabled																										
15	HEAT CS	OFFICE	Disabled																										
16	HEAT CS	OFFICE 2	Disabled																										
17	OPT STAND	Stock Room	Disabled																										

3.6.5 Test Mode

<p>In this example, one Zone 3 is in test mode. A number of zones can be put into test at the same time if required. The test can be silent, or with sounders. If the sounder option is chosen, only sounders within the same zone as the test device are operated.</p>	
<p>As devices are tested, the screen changes to show the recent tests. Use the arrow to scroll to view older tests if required.</p>	

3.6.6 Multiple Conditions

<p>In the event of multiple conditions, the panel will display the highest priority event. It will display the presence of suppressed events as icons on the top right of the screen. The number of events for each category is shown on the icon. To display any of the suppressed events, press the icon of that event.</p>	
---	--

4 - DESIGNING THE SYSTEM

4.1 DESIGNING THE SYSTEM.....	20
4.2 RECOMMENDED CABLE TYPES AND THEIR LIMITATIONS	20
4.3 LOOP CALCULATIONS	20
4.4 MAXIMUM LOOP CABLE LENGTH RECOMMENDATIONS	21
4.5 BATTERY CALCULATIONS.....	21
4.6 CHOOSING AUDIBLE & VISIBLE WARNING DEVICES.....	21
4.6.1 ADDRESSABLE SOUNDER	21
4.6.2 ADDRESSABLE SOUNDER BASE.....	21
4.6.3 PCB CONVENTIONAL SOUNDER CIRCUITS.....	22
4.6.4 ADVANTAGES AND DISADVANTAGES OF DIFFERENT SOUNDER TYPES	22
4.7 System Spare Capacity.....	23

4.1 DESIGNING THE SYSTEM

The first consideration when designing the fire alarm system is the type or category of fire protection that is required for the building. In the UK this is fully explained in the British Standard BS 5839-1. This contains guidance on how many smoke detectors, heat detectors, call points, sounders etc. should be fitted for the type of coverage that is required.

Next decide on the number of loops of addressable devices that need to be installed. Smart Connect is a single loop panel. The maximum loop capacity is 254 devices (also called points or addresses).

If the building requires more than 254 devices, then several control panels can be networked. The network capacity is 16 panels.

All fire alarm systems must be subdivided into zones, which represent the geographical areas of the building. Smart Connect allows any number of devices to be allocated to a zone. However, it is assumed that a zone will not contain more than 32 fire detectors and/or manual call points, since this would correspond to an unacceptably large search area.

Each panel may be configured to have between 1 and 254 zones.

Although a fire alarm system has to be subdivided into zones, the cause and effect actions applicable to Smart Connect can be based on other groupings as well as zones. The other groupings are panels, Local I/O and points. Cause and effect is described later in this manual.

Whenever possible, give each device as descriptive a label as possible. The better the description, the easier it is to locate in the event of an alarm. The panel allows 47 characters. It may be necessary to use abbreviations to achieve the required label.

Keep the design of the system, and any changes to it well documented. This makes it easier to trace any configuration errors during installation & commissioning.

4.2 RECOMMENDED CABLE TYPES AND THEIR LIMITATIONS

All wiring must be installed to meet the current versions of BS5839: Pt1 and BS 7671 (IEE Wiring Regulations) standards. Other National standards of fire alarm system installation should be adhered to where applicable.

Screened cables should be used throughout the installation to help shield the Panel from outside interference and ensure EMC compatibility.

The two categories of cable according to BS5839: Pt1 "Fire Detection and Alarm Systems for Buildings (Code of Practice for System Design, Installation and Servicing)" are:

Standard fire resisting cable – to PH30 classification of EN 50200 (including the 30 minute survival time of Annex E)

Enhanced fire resisting cable – to PH120 classification of EN 50200 (including the 120 minute survival time of BS 8434-2)

(Note that all cables should be at least 1mm² cross section)

On the Smart Connect Panel the general recommendation would be to use standard fire resistant cable, such as Firetuff™, FP200 or an equivalent. These cables are screened, and will provide good EMC shielding when properly grounded at the panel. Certain system specifications may demand the use of a particular type of cable and due regard should be paid to this fact. For non-BS5839 installations, other cable types may be suitable.

Depending on the environment, the cables may need mechanical protection (such as a conduit).

4.3 LOOP CALCULATIONS

Like most addressable systems, it is important that a system is designed within the panel's limits. The following Limits should not be exceeded:-

Characteristic	Limit
Maximum loop load	500mA
Maximum Quiescent loop load	400mA
Maximum cable resistance	22 ohms per core (36 Ohms from presentation)
Maximum cable capacitance	400nF core to screen
	200nF core to core
Minimum loop voltage	24V DC

4.4 MAXIMUM LOOP CABLE LENGTH RECOMMENDATIONS

With an addressable system, some care must be taken when calculating the appropriate cable gauge for the system. The main limitation is that during an alarm condition (maximum current draw), the voltage at all devices must be at least 24 Volts with at least 2.5V of superimposed data signal.

The exact calculation equations are beyond the scope of this manual, because of the distributed load of the sounders on the loop, but the following table gives a rough guide for maximum cable lengths at various current loads for 3 different cable gauges.

MAXIMUM LOOP CURRENT (IN ALARM)	500 mA	400 mA	300 mA	200 mA
1mm CSA cable	500m	625m	830m	1250m
1.5mm CSA cable	750m	930m	1250m	1870m
2.5mm CSA cable	1000m	1250m	1660m	2500m

EG. A system with a maximum load of 300mA using 1.5mm cable can have a maximum loop run of 1250m end to end. When installed the cable characteristics should meet the following parameters:-

- +ve in to +ve out less than 22 ohms.
- -ve in to -ve out less than 22 ohms (may need to temporarily disable isolators to measure).
- +ve to -ve greater than 500k ohm.
- +ve to Earth greater than 1M ohm.
- -ve to Earth greater than 1M ohm.
- +ve to -ve less than 50 mV pickup (on AC & DC scales).
- +ve to -ve Capacitance Less than 0.5uF.
- +ve to Earth Capacitance Less than 0.5uF.
- -ve to Earth Capacitance Less than 0.5uF

4.5 BATTERY CALCULATIONS

All systems will have a required stand by time and alarm time. The usual Standby times are 24 hours, 48 hours, or 72 hours, depending on the type of system. Generally 30 minutes of alarm time is considered sufficient.

Information on calculating the required battery size can be found later in this manual. Alternatively, a battery calculation spreadsheet is available. Please contact your distributor for details.

4.6 CHOOSING AUDIBLE & VISIBLE WARNING DEVICES

There are a number of options for Audible & visual Devices that can be directly or indirectly connected to the loop of a Smart Connect panel:

- A maximum of 64 loop powered sounders are permitted on each loop (which can be either stand-alone sounders or sounder bases.
- A maximum of 254 devices can be connected to the loop, with addresses 1 to 254 which can occur in any order.
- Short circuit isolators should be used to prevent losing the whole loop in the event of a single short circuit fault. They should be fitted to each zone boundary, such that any short circuit will only affect the devices in 1 zone.

4.6.1 ADDRESSABLE SOUNDER

This type of sounder takes one of the 254 addresses available on each loop. The address is set with the programming tool. It can be activated individually, or in groups related to its zone number, as determined by the cause and effect programmed.


4.6.2 ADDRESSABLE SOUNDER BASE

This consists of an addressable sounder in the base of an addressable detector. The sounder and detector are set to different addresses, i.e. two devices are located at the same position on a loop but occupy two addresses. The address is set with the programming tool, or with dip switches, depending on the model used. It can be activated individually, or in groups related to its zone number, as determined by the cause and effect programmed.


4.6.3 PCB CONVENTIONAL SOUNDER CIRCUITS

The termination PCB has 2 conventional sounder circuit outputs, with a maximum capacity of 100 mA each. Please note that conventional sounders should be wired as shown in the diagram below:

*The descriptions of sounders in this section also apply to flashers and combined sounder / flashers.



Note: If non-polarised alarm devices (e.g. some types of old mechanical bell, or a relay) are used, then a diode will have to be placed in line with the device to enable fault monitoring. They may also need a back EMF protection diode. (symptoms: Chattering sounder relays that don't turn off).



4.6.4 ADVANTAGES AND DISADVANTAGES OF DIFFERENT SOUNDER TYPES

SOUNDER TYPE	ADVANTAGE	DISADVANTAGE
Conventional	Wide range of devices. Devices tend to be cheaper. Immediate start / stop. No quiescent current.	Needs extra cabling. All sounders on each circuit start together
Stand-Alone Addressable or Addressed Sounder Base	No extra cabling. Can be individually started. Can use any type of detector.	Tends to be more expensive. Maximum 64 per loop. Quiescent current relatively high. Uses an address.
Combined Detector sounder	Can be individually started. Only uses one address space. Uses a standard detector base.	Only available as an optical detector. Not available as heat, opto-heat, dual optical etc
Addressable Sounder Circuit Controller	Wide range of devices. Devices tend to be cheaper. Can Add many sounder circuits to system. Sounder circuit can be assigned to zone.	Needs Extra Cabling. Needs External PSU. Uses device Address.

4.7 System Spare Capacity

The UK Fire alarm system code of Practice for Designing, Installing, Commissioning & maintaining fire alarm systems, BS5839 recommends allowing at least 25% free capacity when designing a fire system.

This is a good precaution as it allows for:-

- Changes to the system requirements before the site is finished
- Additional devices identified as part of the commissioning process
- Future Changes to the building layout (eg partitioning an open plan area)

If a system is designed to full capacity, any small additions might mean substantial changes (network an extra panel, or change panel to an alternative model)

5 - INSTALLING THE PANEL

5.1 MOUNTING THE FIRE ALARM CONTROL PANEL.....	25
5.2 LOCATING THE FIRE ALARM CONTROL PANEL	25
5.3 FIXING THE BACK BOX TO THE WALL.....	25
5.4 MAINS WIRING RECOMMENDATIONS	26
5.5 PLANNING CABLE ENTRY	26
5.6 CONNECTING THE MAINS POWER	26
5.7 CONNECTING THE BATTERIES.....	27

5.1 MOUNTING THE FIRE ALARM CONTROL PANEL

The Smart Connect comes with many cable entry holes. If another entry hole is required, it is strongly recommended that the panel door is removed to avoid accidental damage. Also, the back plate which holds the loop cards and power supply should be removed and stored in a safe place. This would also help while fixing the back box to the wall.

5.2 LOCATING THE FIRE ALARM CONTROL PANEL

The control panel should be installed in accordance with the following recommendations:-

The panel should be close to the main entrance of the building, so that it can be viewed by any fire-fighting personnel entering the building.

- It should be fitted to a sturdy wall that will not flex unnecessarily.
- It should ideally be mounted at eye level, in order for it to be viewed without need of a ladder.
- It should be installed in a dry, weatherproof place, preferably NOT in direct sunlight.
- It should be easily accessible, so that the responsible person can perform their regular fire alarm checks.

5.3 FIXING THE BACK BOX TO THE WALL




Figure 1

Figure 1: Plan view inside the enclosure without PCBs. Side view for surface installation. (Dimensions: mm)

Fix the enclosure to the wall using the three mounting holes provided (2 circular holes near the bottom of the rear face and one 'keyhole' near the top of the rear face).

Check the build and condition of the wall to decide a suitable screw fixing. The mounting holes are designed for No 8 roundhead or countersunk woodscrews (or similar). Remove any debris from the enclosure. Take care not to damage the FACP during installation.

5.4 MAINS WIRING RECOMMENDATIONS

The Mains supply to the FACP is fixed wiring, using **Fire resisting** 3-core cable (Between 1 mm² and 2.5mm²), fed from an isolating double pole switch fused spur, fused at 3A. **IT SHOULD NOT BE CONNECTED THROUGH AN RCD.** This should be secure from unauthorised operation and be marked 'FIRE ALARM: DO NOT SWITCH OFF'. The supply must be exclusive to the Fire Panel. **MAKE SURE ANY SPARE ENTRY HOLES ARE COVERED WITH THE GROMMETS PROVIDED.**

For information on how to connect Mains to the Panel's Power Supply PCB, see Section 6.

Also refer to rating information on the mains cover inside the FACP.

5.5 PLANNING CABLE ENTRY

Fig.2 below shows the location of the cable entries to facilitate planning of wiring to be brought to the panel.

The Knock-out cable entries can be easily removed by Tapping with a suitable screwdriver or chisel from outside the control panel box. Alternatively, the entry can be drilled out, using a 19mm hole cutter. Care should be taken if using a drill. Consider removing the main PCB to prevent damaging it.

5.6 CONNECTING THE MAINS POWER




Figure 2: Wiring the mains connection

The panel should be connected to a mains supply by a 3A rated spur to the fuse box with 1mm² to 2.5mm² 3-core cables. Nothing else should be connected to this supply. The cable should be fire resistant. NB It is recommended that the mains cable should pass twice through the ferrite supplied with the panel, to improve the panel's immunity to electromagnetic interference. The ferrite should be positioned between the mains entry port and the power supply cage.

Smart Connect Single Loop Touch Screen Panel

The AC Live (L), Earth (E) and Neutral (N) connections are marked on the power supply cage. It is essential that the mains Earth cable is connected to the PSU's Earth terminal. The incoming mains cable should be kept separate from the loop cables to help minimise mains interference.

MAKE SURE ANY SPARE ENTRY HOLES THAT HAVE BEEN OPENED, BUT NOT USED ARE COVERED WITH SUITABLE GROMMETS OR BLANKING SCREWS

It is advisable to apply power to the panel before connecting any devices, to check for correct operation, and to familiarise yourself with the fire alarm panels controls.

If a knockout is removed, fill the hole with a suitable cable gland. If any knockout is removed, but subsequently not used, it should be covered up.

The 230V AC Mains cable must be fed into the enclosure via one of the cable entries at the top right corner of the back box. (Refer to "Connecting the Mains Power" in Section 6.1).

5.7 CONNECTING THE BATTERIES




Figure 3: Battery location and connection details.

To calculate the exact requirement, use the equation in the STANDBY BATTERY REQUIREMENTS section.

The two batteries are wired in series.

The **+ve** of one battery is connected to the **red** battery lead.

The **-ve** of the other battery is connected to the **black** battery lead.

The **-ve** of the first battery is connected to the **+ve** of the second battery using the link wire supplied.

Recommended Battery Types: Powersonic 12V, 7 Ah

Other makes and sizes of battery may be suitable. Calculate the standby requirements to determine the most suitable size of battery

6 - INSTALLING THE DEVICES

6.1 ADDRESSABLE LOOP WIRING	29
6.2 ADDRESSABLE LOOPS (Pre commissioning check)	29
6.3 SPECIFIC DEVICE WIRING INSTRUCTIONS.....	30
6.3.1 CP3/AD Manual Call Point	30
6.3.2 MKII detectors (All types)	31
6.3.3 ZAI - MI Input Module	32
6.3.4 ZAIO – MI Input/output Module.....	32
6.3.5 ZASC – MI Sounder Control Module.....	32
6.3.6 ZAZM – MI Conventional Zone Module	33
6.3.7 Xtratone Sounder/Sounder Flasher	33
6.3.8 Sandwich Sounder.....	34
6.3.9 Remote LED Indicator	34
6.4 SETTING THE DEVICE ADDRESS (DETECTORS, CALL POINTS, SOUNDERS & INTERFACE UNITS).....	36
6.4.1 SOFT ADDRESSING	36
6.4.2 DIP SWITCH ADDRESSING.....	36
6.4.3 DIP SWITCH ADDRESS SETTINGS - FULL TABLE.....	37
6.5 FIRE RELAY (VOLTAGE FREE CHANGE OVER CONTACTS).....	39
6.6 FAULT RELAY (VOLTAGE FREE CHANGE OVER CONTACTS)	39
6.7 AUXILIARY DC OUTPUT	39
6.8 FIELD DEVICE TERMINATION	40

6.1 ADDRESSABLE LOOP WIRING

The Smart Connect has one addressable loop. Addressable detectors, addressable call points, addressable loop powered sounders and several other interface units can be fitted to this loop. A MAXIMUM OF 254 ADDRESSES CAN BE CONNECTED TO THE LOOP. We recommend that the first and last devices on a loop have isolator bases fitted. Also the last device on each zone should have an isolator fitted. This is to prevent a short circuit fault in one zone affecting another zone. The screen cable at each end of the loop (not shown below) must be connected to the Panel's earth bar.




Figure 5: Example of addressable loop wiring (top) & connections to loop cards (bottom)

6.2 ADDRESSABLE LOOPS (Pre commissioning check)


At this stage it is important to remember devices (e.g. detectors, call points, sounders etc.) should not be connected yet, if a high voltage "Megger" type tester is to be used to check for continuity of the loop wiring.

Pre-Commissioning Cable Checks

- +ve in to +ve out less than 22 ohms.
- -ve in to -ve out less than 22 ohms (may need to temporarily disable isolators to measure).
- +ve to -ve greater than 500k ohm.
- +ve to Earth greater than 1M ohm.
- -ve to Earth greater than 1M ohm.
- +ve to -ve less than 50 mV pickup (on AC & DC scales).
- +ve to -ve Capacitance Less than 0.5µF.
- +ve to Earth Capacitance Less than 0.5µF.
- -ve to Earth Capacitance Less than 0.5µF

6.3 SPECIFIC DEVICE WIRING INSTRUCTIONS

6.3.1 CP3/AD Manual Call Point



The CP3/AD call point has a built in isolator which can be wired in circuit or not used. This is done by means of not wiring to the negative out terminal on the call point. The following terminals are used for connecting the call point.


- 2 x Negative in terminals (note if you only connect to the negative in terminals then the isolator is bypassed)
- 1 x Positive in terminal
- 1 x Positive out terminal
- 1 x Negative out terminal (note if used puts the isolator in circuit)
- 1 x Earth terminal used to connect the cable screen

Protocol setting jumper link must be removed for MKII protocol



6.3.2 MKII detectors (All types)

➤ Base Connection



The connection for the detectors bases is made as follows:
Terminal L1IN is -ve (Blue)
Terminal L2 is +ve (Brown)
These are the only two connections required.




Deep Base MKII-CB/D




Common Base MKII-CB

6.3.3 ZAI - MI Input Module




The end of line resistor value is 20KΩ and the trigger resistor value is 1kΩ.

6.3.4 ZAI0 - MI Input/output Module



The end of line resistor value is 20KΩ and the trigger resistor value is 1kΩ.


6.3.5 ZASC - MI Sounder Control Module



The ZASC requires an external 24vdc power supply (as shown in the above diagram). The EOL for the sounder circuit is 4K7 Ω. When using the ZASC make sure the PSU being used has a fault output relay, so that in the event of a power supply fault it is reported to the control panel.

Note: All Power Supplies used on fire alarm systems MUST comply with EN54 part 4

6.3.6 ZAZM – MI Conventional Zone Module




The ZAZM powers the conventional zone from the addressable systems loop, so no external power supply is required. The EOL for the zone is 6.2KΩ.

6.3.7 Xtratone Sounder/Sounder Flasher



The Xtratone sounder or sounder flasher is a wall mount sounder. The programming of the sounder is done via the D.I.L switch mounted on the inside (front). It may also be programmed via the handheld programming tool.




Connecting the sounder is done using the terminals in the back box of the device. Please refer to the above diagram.

6.3.8 Sandwich Sounder

The sandwich sounder has no wiring to connect as it just clips straight on to a standard base. It will run as a platform sounder using no address, and is controlled by the detector fitted to it. It can also be given an address via the handheld programming tool making it an addressable sounder. **(Note: If the sandwich sounder has NO ADDRESS it will ONLY function with an addressed detector fitted on top of it.)**



MKII-SSB



6.3.9 Remote LED Indicator



Ceiling Mount (MKII-ARL/C)



Wall Mount (MKII-ARL/W)

There are two versions of the remote LED, Wall mounted and Ceiling mounted. The ceiling mounted version requires a standard detector base.

Each version of the remote LED can monitor 1 or up to 12 devices. The way in which the LED is programmed is either via the D.I.L switches on the device or soft addressing via the handheld programmer.

Connection to an Addressable Detector




Fig 1

Fig 1: shows the connections for a ceiling mount version remote LED

Smart Connect Single Loop Touch Screen Panel

Connection to an Addressable Detector




Fig 2

Fig 2: shows the connections for a wall mount version remote LED

6.4 SETTING THE DEVICE ADDRESS (DETECTORS, CALL POINTS, SOUNDERS & INTERFACE UNITS)

Note that the devices do not need to be addressed sequentially along the loop. Technically they can be addressed in any sequence. But addressing them sequentially will help in fault finding, should there be a problem with the loop wiring.


6.4.1 SOFT and HARD PROGRAMMING/ADDRESSING



The MKII Handheld Programmer is designed to complement all MKII devices and to assist the commissioning engineer on site. The unit will softly address all devices without using the incorporated dip-switch on the field devices. Smoke and heat detectors can be tested when plugged on the programmer and alarm LED's can be verified prior to installation. The MKII Programmer can also re-program the OPT-HEAT detectors to either heat or smoke detector.

6.4.2 DIP SWITCH ADDRESSING

Some Devices are addressed with a dip switch



The Address setting is binary, with the ON position being binary 0, and the OFF position being binary 1

If you are not familiar with binary, check the table on the following page, or use the following rule:

- Switch 8 ON = Add 128
- Switch 7 ON = Add 64
- Switch 6 ON = Add 32
- Switch 5 ON = Add 16
- Switch 4 ON = Add 8
- Switch 3 ON = Add 4
- Switch 2 ON = Add 2
- Switch 1 ON = Add 1

The example shown would be:
switches 6, 4 & 1 = $32 + 8 + 1 =$ Address 41

6.4.3 DIP SWITCH ADDRESS SETTINGS - FULL TABLE

ADDRESS	SWITCHES								ADDRESS	SWITCHES								ADDRESS	SWITCHES										
	1	2	3	4	5	6	7	8		1	2	3	4	5	6	7	8		1	2	3	4	5	6	7	8			
0	=	N	O	T		U	S	E	D	43	=	OFF	OFF	ON	OFF	ON	OFF	ON	ON	86	=	ON	OFF	OFF	ON	OFF	ON	OFF	ON
1	=	OFF	ON	ON	ON	ON	ON	ON	ON	44	=	ON	ON	OFF	OFF	ON	OFF	ON	ON	87	=	OFF	OFF	OFF	ON	OFF	ON	OFF	ON
2	=	ON	OFF	ON	ON	ON	ON	ON	ON	45	=	OFF	ON	OFF	OFF	ON	OFF	ON	ON	88	=	ON	ON	ON	OFF	OFF	ON	OFF	ON
3	=	OFF	OFF	ON	ON	ON	ON	ON	ON	46	=	ON	OFF	OFF	OFF	ON	OFF	ON	ON	89	=	OFF	ON	ON	OFF	OFF	ON	OFF	ON
4	=	ON	ON	OFF	ON	ON	ON	ON	ON	47	=	OFF	OFF	OFF	OFF	ON	OFF	ON	ON	90	=	ON	OFF	ON	OFF	OFF	ON	OFF	ON
5	=	OFF	ON	OFF	ON	ON	ON	ON	ON	48	=	ON	ON	ON	ON	OFF	OFF	ON	ON	91	=	OFF	OFF	ON	OFF	OFF	ON	OFF	ON
6	=	ON	OFF	OFF	ON	ON	ON	ON	ON	49	=	OFF	ON	ON	ON	OFF	OFF	ON	ON	92	=	ON	ON	OFF	OFF	OFF	ON	OFF	ON
7	=	OFF	OFF	OFF	ON	ON	ON	ON	ON	50	=	ON	OFF	ON	ON	OFF	OFF	ON	ON	93	=	OFF	ON	OFF	OFF	OFF	ON	OFF	ON
8	=	ON	ON	ON	OFF	ON	ON	ON	ON	51	=	OFF	OFF	ON	ON	OFF	OFF	ON	ON	94	=	ON	OFF	OFF	OFF	OFF	ON	OFF	ON
9	=	OFF	ON	ON	OFF	ON	ON	ON	ON	52	=	ON	ON	OFF	ON	OFF	OFF	ON	ON	95	=	OFF	OFF	OFF	OFF	OFF	ON	OFF	ON
10	=	ON	OFF	ON	OFF	ON	ON	ON	ON	53	=	OFF	ON	OFF	ON	OFF	OFF	ON	ON	96	=	ON	ON	ON	ON	ON	OFF	OFF	ON
11	=	OFF	OFF	ON	OFF	ON	ON	ON	ON	54	=	ON	OFF	OFF	ON	OFF	OFF	ON	ON	97	=	OFF	ON	ON	ON	ON	OFF	OFF	ON
12	=	ON	ON	OFF	OFF	ON	ON	ON	ON	55	=	OFF	OFF	OFF	ON	OFF	OFF	ON	ON	98	=	ON	OFF	ON	ON	ON	OFF	OFF	ON
13	=	OFF	ON	OFF	OFF	ON	ON	ON	ON	56	=	ON	ON	ON	OFF	OFF	OFF	ON	ON	99	=	OFF	OFF	ON	ON	ON	OFF	OFF	ON
14	=	ON	OFF	OFF	OFF	ON	ON	ON	ON	57	=	OFF	ON	ON	OFF	OFF	OFF	ON	ON	100	=	ON	ON	OFF	ON	ON	OFF	OFF	ON
15	=	OFF	OFF	OFF	OFF	ON	ON	ON	ON	58	=	ON	OFF	ON	OFF	OFF	OFF	ON	ON	101	=	OFF	ON	OFF	ON	ON	OFF	OFF	ON
16	=	ON	ON	ON	ON	OFF	ON	ON	ON	59	=	OFF	OFF	ON	OFF	OFF	OFF	ON	ON	102	=	ON	OFF	OFF	ON	ON	OFF	OFF	ON
17	=	OFF	ON	ON	ON	OFF	ON	ON	ON	60	=	ON	ON	OFF	OFF	OFF	OFF	ON	ON	103	=	OFF	OFF	OFF	ON	ON	OFF	OFF	ON
18	=	ON	OFF	ON	ON	OFF	ON	ON	ON	61	=	OFF	ON	OFF	OFF	OFF	OFF	ON	ON	104	=	ON	ON	ON	OFF	ON	OFF	OFF	ON
19	=	OFF	OFF	ON	ON	OFF	ON	ON	ON	62	=	ON	OFF	OFF	OFF	OFF	OFF	ON	ON	105	=	OFF	ON	ON	OFF	ON	OFF	OFF	ON
20	=	ON	ON	OFF	ON	OFF	ON	ON	ON	63	=	OFF	OFF	OFF	OFF	OFF	OFF	ON	ON	106	=	ON	OFF	ON	OFF	ON	OFF	OFF	ON
21	=	OFF	ON	OFF	ON	OFF	ON	ON	ON	64	=	ON	ON	ON	ON	ON	ON	OFF	ON	107	=	OFF	OFF	ON	OFF	ON	OFF	OFF	ON
22	=	ON	OFF	OFF	ON	OFF	ON	ON	ON	65	=	OFF	ON	ON	ON	ON	ON	OFF	ON	108	=	ON	ON	OFF	OFF	ON	OFF	OFF	ON
23	=	OFF	OFF	OFF	ON	OFF	ON	ON	ON	66	=	ON	OFF	ON	ON	ON	ON	OFF	ON	109	=	OFF	ON	OFF	OFF	ON	OFF	OFF	ON
24	=	ON	ON	ON	OFF	OFF	ON	ON	ON	67	=	OFF	OFF	ON	ON	ON	ON	OFF	ON	110	=	ON	OFF	OFF	OFF	ON	OFF	OFF	ON
25	=	OFF	ON	ON	OFF	OFF	ON	ON	ON	68	=	ON	ON	OFF	ON	ON	ON	OFF	ON	111	=	OFF	OFF	OFF	OFF	ON	OFF	OFF	ON
26	=	ON	OFF	ON	OFF	OFF	ON	ON	ON	69	=	OFF	ON	OFF	ON	ON	ON	OFF	ON	112	=	ON	ON	ON	ON	OFF	OFF	OFF	ON
27	=	OFF	OFF	ON	OFF	OFF	ON	ON	ON	70	=	ON	OFF	OFF	ON	ON	ON	OFF	ON	113	=	OFF	ON	ON	ON	OFF	OFF	OFF	ON
28	=	ON	ON	OFF	OFF	OFF	ON	ON	ON	71	=	OFF	OFF	OFF	ON	ON	ON	OFF	ON	114	=	ON	OFF	ON	ON	OFF	OFF	OFF	ON
29	=	OFF	ON	OFF	OFF	OFF	ON	ON	ON	72	=	ON	ON	ON	OFF	ON	ON	OFF	ON	115	=	OFF	OFF	ON	ON	OFF	OFF	OFF	ON
30	=	ON	OFF	OFF	OFF	OFF	ON	ON	ON	73	=	OFF	ON	ON	OFF	ON	ON	OFF	ON	116	=	ON	ON	OFF	ON	OFF	OFF	OFF	ON
31	=	OFF	OFF	OFF	OFF	OFF	ON	ON	ON	74	=	ON	OFF	ON	OFF	ON	ON	OFF	ON	117	=	OFF	ON	OFF	ON	OFF	OFF	OFF	ON
32	=	ON	ON	ON	ON	ON	OFF	ON	ON	75	=	OFF	OFF	ON	OFF	ON	ON	OFF	ON	118	=	ON	OFF	OFF	ON	OFF	OFF	OFF	ON
33	=	OFF	ON	ON	ON	ON	OFF	ON	ON	76	=	ON	ON	OFF	OFF	ON	ON	OFF	ON	119	=	OFF	OFF	OFF	ON	OFF	OFF	OFF	ON
34	=	ON	OFF	ON	ON	ON	OFF	ON	ON	77	=	OFF	ON	OFF	OFF	ON	ON	OFF	ON	120	=	ON	ON	ON	OFF	OFF	OFF	OFF	ON
35	=	OFF	OFF	ON	ON	ON	OFF	ON	ON	78	=	ON	OFF	OFF	OFF	ON	ON	OFF	ON	121	=	OFF	ON	ON	OFF	OFF	OFF	OFF	ON
36	=	ON	ON	OFF	ON	ON	OFF	ON	ON	79	=	OFF	OFF	OFF	OFF	ON	ON	OFF	ON	122	=	ON	OFF	ON	OFF	OFF	OFF	OFF	ON
37	=	OFF	ON	OFF	ON	ON	OFF	ON	ON	80	=	ON	ON	ON	ON	OFF	ON	OFF	ON	123	=	OFF	OFF	ON	OFF	OFF	OFF	OFF	ON
38	=	ON	OFF	OFF	ON	ON	OFF	ON	ON	81	=	OFF	ON	ON	ON	OFF	ON	OFF	ON	124	=	ON	ON	OFF	OFF	OFF	OFF	OFF	ON
39	=	OFF	OFF	OFF	ON	ON	OFF	ON	ON	82	=	ON	OFF	ON	ON	OFF	ON	OFF	ON	125	=	OFF	ON	OFF	OFF	OFF	OFF	OFF	ON
40	=	ON	ON	ON	OFF	ON	OFF	ON	ON	83	=	OFF	OFF	ON	ON	OFF	ON	OFF	ON	126	=	ON	OFF	OFF	OFF	OFF	OFF	OFF	ON
41	=	OFF	ON	ON	OFF	ON	OFF	ON	ON	84	=	ON	ON	OFF	ON	OFF	ON	OFF	ON	127	=	OFF	ON						
42	=	ON	OFF	ON	OFF	ON	OFF	ON	ON	85	=	OFF	ON	OFF	ON	OFF	ON	OFF	ON										

Smart Connect Single Loop Touch Screen Panel

ADDRESS	SWITCHES								ADDRESS	SWITCHES								ADDRESS	SWITCHES									
	1	2	3	4	5	6	7	8		1	2	3	4	5	6	7	8		1	2	3	4	5	6	7	8		
128	=	ON	ON	ON	ON	ON	ON	OFF	171	=	OFF	OFF	ON	OFF	ON	OFF	ON	OFF	214	=	ON	OFF	OFF	ON	OFF	ON	OFF	OFF
129	=	OFF	ON	ON	ON	ON	ON	OFF	172	=	ON	ON	OFF	OFF	ON	OFF	ON	OFF	215	=	OFF	OFF	OFF	ON	OFF	ON	OFF	OFF
123	=	ON	OFF	ON	ON	ON	ON	OFF	173	=	OFF	ON	OFF	OFF	ON	OFF	ON	OFF	216	=	ON	ON	ON	OFF	OFF	ON	OFF	OFF
131	=	OFF	OFF	ON	ON	ON	ON	OFF	174	=	ON	OFF	OFF	OFF	ON	OFF	ON	OFF	217	=	OFF	ON	ON	OFF	OFF	ON	OFF	OFF
132	=	ON	ON	OFF	ON	ON	ON	OFF	175	=	OFF	OFF	OFF	OFF	ON	OFF	ON	OFF	218	=	ON	OFF	ON	OFF	OFF	ON	OFF	OFF
133	=	OFF	ON	OFF	ON	ON	ON	OFF	176	=	ON	ON	ON	ON	OFF	OFF	ON	OFF	219	=	OFF	OFF	ON	OFF	OFF	ON	OFF	OFF
134	=	ON	OFF	OFF	ON	ON	ON	OFF	177	=	OFF	ON	ON	ON	OFF	OFF	ON	OFF	220	=	ON	ON	OFF	OFF	OFF	ON	OFF	OFF
135	=	OFF	OFF	OFF	ON	ON	ON	OFF	178	=	ON	OFF	ON	ON	OFF	OFF	ON	OFF	221	=	OFF	ON	OFF	OFF	OFF	ON	OFF	OFF
136	=	ON	ON	ON	OFF	ON	ON	OFF	179	=	OFF	OFF	ON	ON	OFF	OFF	ON	OFF	222	=	ON	OFF	OFF	OFF	OFF	ON	OFF	OFF
137	=	OFF	ON	ON	OFF	ON	ON	OFF	180	=	ON	ON	OFF	ON	OFF	OFF	ON	OFF	223	=	OFF	OFF	OFF	OFF	OFF	ON	OFF	OFF
138	=	ON	OFF	ON	OFF	ON	ON	OFF	181	=	OFF	ON	OFF	ON	OFF	OFF	ON	OFF	224	=	ON	ON	ON	ON	ON	OFF	OFF	OFF
139	=	OFF	OFF	ON	OFF	ON	ON	OFF	182	=	ON	OFF	OFF	ON	OFF	OFF	ON	OFF	225	=	OFF	ON	ON	ON	ON	OFF	OFF	OFF
140	=	ON	ON	OFF	OFF	ON	ON	OFF	183	=	OFF	OFF	OFF	ON	OFF	OFF	ON	OFF	226	=	ON	OFF	ON	ON	ON	OFF	OFF	OFF
141	=	OFF	ON	OFF	OFF	ON	ON	OFF	184	=	ON	ON	ON	OFF	OFF	OFF	ON	OFF	227	=	OFF	OFF	ON	ON	ON	OFF	OFF	OFF
142	=	ON	OFF	OFF	OFF	ON	ON	OFF	185	=	OFF	ON	ON	OFF	OFF	OFF	ON	OFF	228	=	ON	ON	OFF	ON	ON	OFF	OFF	OFF
143	=	OFF	OFF	OFF	OFF	ON	ON	OFF	186	=	ON	OFF	ON	OFF	OFF	OFF	ON	OFF	229	=	OFF	ON	OFF	ON	ON	OFF	OFF	OFF
144	=	ON	ON	ON	ON	OFF	ON	OFF	187	=	OFF	OFF	ON	OFF	OFF	OFF	ON	OFF	230	=	ON	OFF	OFF	ON	ON	OFF	OFF	OFF
145	=	OFF	ON	ON	ON	OFF	ON	OFF	188	=	ON	ON	OFF	OFF	OFF	OFF	ON	OFF	231	=	OFF	OFF	OFF	ON	ON	OFF	OFF	OFF
146	=	ON	OFF	ON	ON	OFF	ON	OFF	189	=	OFF	ON	OFF	OFF	OFF	OFF	ON	OFF	232	=	ON	ON	ON	OFF	ON	OFF	OFF	OFF
147	=	OFF	OFF	ON	ON	OFF	ON	OFF	190	=	ON	OFF	OFF	OFF	OFF	OFF	ON	OFF	233	=	OFF	ON	ON	OFF	ON	OFF	OFF	OFF
248	=	ON	ON	OFF	ON	OFF	ON	OFF	191	=	OFF	OFF	OFF	OFF	OFF	OFF	ON	OFF	234	=	ON	OFF	ON	OFF	ON	OFF	OFF	OFF
149	=	OFF	ON	OFF	ON	OFF	ON	OFF	192	=	ON	ON	ON	ON	ON	ON	OFF	OFF	235	=	OFF	OFF	ON	OFF	ON	OFF	OFF	OFF
150	=	ON	OFF	OFF	ON	OFF	ON	OFF	193	=	OFF	ON	ON	ON	ON	ON	OFF	OFF	236	=	ON	ON	OFF	OFF	ON	OFF	OFF	OFF
151	=	OFF	OFF	OFF	ON	OFF	ON	OFF	194	=	ON	OFF	ON	ON	ON	ON	OFF	OFF	237	=	OFF	ON	OFF	OFF	ON	OFF	OFF	OFF
152	=	ON	ON	ON	OFF	OFF	ON	OFF	195	=	OFF	OFF	ON	ON	ON	ON	OFF	OFF	238	=	ON	OFF	OFF	OFF	ON	OFF	OFF	OFF
153	=	OFF	ON	ON	OFF	OFF	ON	OFF	196	=	ON	ON	OFF	ON	ON	ON	OFF	OFF	239	=	OFF	OFF	OFF	OFF	ON	OFF	OFF	OFF
154	=	ON	OFF	ON	OFF	OFF	ON	OFF	197	=	OFF	ON	OFF	ON	ON	ON	OFF	OFF	240	=	ON	ON	ON	ON	OFF	OFF	OFF	OFF
155	=	OFF	OFF	ON	OFF	OFF	ON	OFF	198	=	ON	OFF	OFF	ON	ON	ON	OFF	OFF	241	=	OFF	ON	ON	ON	OFF	OFF	OFF	OFF
156	=	ON	ON	OFF	OFF	OFF	ON	OFF	199	=	OFF	OFF	OFF	ON	ON	ON	OFF	OFF	242	=	ON	OFF	ON	ON	OFF	OFF	OFF	OFF
157	=	OFF	ON	OFF	OFF	OFF	ON	OFF	200	=	ON	ON	ON	OFF	ON	ON	OFF	OFF	243	=	OFF	OFF	ON	ON	OFF	OFF	OFF	OFF
158	=	ON	OFF	OFF	OFF	OFF	ON	OFF	201	=	OFF	ON	ON	OFF	ON	ON	OFF	OFF	244	=	ON	ON	OFF	ON	OFF	OFF	OFF	OFF
159	=	OFF	OFF	OFF	OFF	OFF	ON	OFF	202	=	ON	OFF	ON	OFF	ON	ON	OFF	OFF	245	=	OFF	ON	OFF	ON	OFF	OFF	OFF	OFF
160	=	ON	ON	ON	ON	ON	OFF	OFF	203	=	OFF	OFF	ON	OFF	ON	ON	OFF	OFF	246	=	ON	OFF	OFF	ON	OFF	OFF	OFF	OFF
161	=	OFF	ON	ON	ON	ON	OFF	OFF	204	=	ON	ON	OFF	OFF	ON	ON	OFF	OFF	247	=	OFF	OFF	OFF	ON	OFF	OFF	OFF	OFF
162	=	ON	OFF	ON	ON	ON	OFF	OFF	205	=	OFF	ON	OFF	OFF	ON	ON	OFF	OFF	248	=	ON	ON	ON	OFF	OFF	OFF	OFF	OFF
163	=	OFF	OFF	ON	ON	ON	OFF	OFF	206	=	ON	OFF	OFF	OFF	ON	ON	OFF	OFF	249	=	OFF	ON	ON	OFF	OFF	OFF	OFF	OFF
164	=	ON	ON	OFF	ON	ON	OFF	OFF	207	=	OFF	OFF	OFF	OFF	ON	ON	OFF	OFF	250	=	ON	OFF	ON	OFF	OFF	OFF	OFF	OFF
165	=	OFF	ON	OFF	ON	ON	OFF	OFF	208	=	ON	ON	ON	ON	OFF	ON	OFF	OFF	251	=	N	O	T		U	S	E	D
166	=	ON	OFF	OFF	ON	ON	OFF	OFF	209	=	OFF	ON	ON	ON	OFF	ON	OFF	OFF	252	=	N	O	T		U	S	E	D
167	=	OFF	OFF	OFF	ON	ON	OFF	OFF	210	=	ON	OFF	ON	ON	OFF	ON	OFF	OFF	253	=	N	O	T		U	S	E	D
168	=	ON	ON	ON	OFF	ON	OFF	OFF	211	=	OFF	OFF	ON	ON	OFF	ON	OFF	OFF	254	=	N	O	T		U	S	E	D
169	=	OFF	ON	ON	OFF	ON	OFF	OFF	212	=	ON	ON	OFF	ON	OFF	ON	OFF	OFF	255	=	N	O	T		U	S	E	D
170	=	ON	OFF	ON	OFF	ON	OFF	OFF	213	=	OFF	ON	OFF	ON	OFF	ON	OFF	OFF										

6.5 FIRE RELAY (VOLTAGE FREE CHANGEOVER CONTACTS)





Figure 3: Connections for fire relay, fault relay, conventional sounders and auxiliary DC outputs.

The fire relay changes over in any fire condition, and can be used for driving local fire fighting equipment such as sprinkler systems, magnetic door holders, air conditioning shut off, auto diallers etc.

NB In the quiescent condition, there is electrical continuity between C and NC. In the fire condition, there is continuity between C and NO.

6.6 FAULT RELAY (VOLTAGE FREE CHANGEOVER CONTACTS)

The fault relay is energised in the quiescent condition. This allows the relay to indicate any fault with a change of state, even in the event of total power loss. The terminals are marked for the quiescent running of the panel.



6.7 AUXILIARY DC OUTPUT

This 24V DC output is provided to support low power requirements (100mA max). A separate power supply will be required for higher current applications.

6.8 FIELD DEVICE TERMINATION




Figure 4: Connecting cables to the Smart Connect panel.

All cables should enter the enclosure via a cable gland, and the cable shields must be connected to the earth bar. Figure 4 illustrates how the mains cable and an addressable loop cable are connected to the panel. All other screens must be terminated at the brass earthing strip.

MAKE SURE ANY UNUSED ENTRY HOLES ARE COVERED.



7 - PANEL SET UP

7.1 INITIAL PANEL SET UP	42
7.2 SETTING TIME AND DATE	42
7.3 CREATING AN INSTALLATION NAME	42
7.4 PASSWORDS	43
7.5 CONFIGURING THE LOOP	43
7.6 ZONE LABELS.....	44
7.7 ADDRESS LABELS AND ZONING DEVICES.....	44
7.8 SETTING DEVICE OPTIONS	46

7.1 INITIAL PANEL SET UP

The Smart Connect panel is supplied configured ready for installation. But there are a few settings that may need to be altered.

7.2 SETTING TIME AND DATE

<p>Press the screen. The panel prompts for a user and password. Select Engineer, and enter the Engineer (Access Level 3) password (default is 9999) Press the access menu icon, followed by the System Icon.</p>	
<p>Select the Clock tab. Alter the time as required. Press the exit button to leave the menu.</p>	
<p>Pressing arrow (up) or arrow (down) changes the setting by 1. To make a bigger adjustment, press the number and a keypad appears to enter the new value. Press tick to accept the value. When all values are correct, press the exit icon.</p>	

7.3 CREATING AN INSTALLATION NAME

<p>From the installer menu, press the System Icon. Select the strings tab. Enter the Installation Name, Maintenance Company and contact number. Press the exit button to leave the menu.</p>	
--	--

7.4 PASSWORDS

From the installer menu, press the System Icon.

Select the USERS tab.


To change a user name, press user name.

To change a password, press the password. The panel prompts to enter the new password twice

To delete a user, enter the password as blank.

Any unused user should have the password left blank

Press the exit button to leave the menu.




7.5 CONFIGURING THE LOOP

Press the screen. The panel prompts for a password.

Enter the Engineer (Access Level 3) password (default is 9999)

Press the loop Icon.

The panel proceeds to learn the loop.



When the configuration is complete, the panel displays a summary of the devices found

Summary			
Total	: 246	Double address	: 0
HEAT A1S	: 56	HEAT CS	: 67
RF HEAT	: 0	OPT STANDARD	: 53
OPT INTEGRAT	: 0	OPTO HEAT	: 25
RF OPTO	: 10	RF OPTO HEAT	: 0
Unknown	: 0	RF HEAT ROR	: 0
		OPTO HIGH	: 0
		OPTO MULTI	: 0
		MIDI SOUNDE	: 0



To view details of the configuration, click the detail tab. This shows the device type found at each address, and also shows whether it was seen from Side A or Side B (to help locate CABLE BREAKS), and it also shows if the device seen is different to the previous database [!!] (IE has the device type been changed), or if it is the same as previously configured [=]

Press the exit button to save configuration and leave the menu.

Summary				
Detailed				
EN54 - 13				
Address	Type	Side A	Side B	dBase
1	MCP ADDRESSABLE	X	X	=
2	INPUT MODULE	X	X	=
3	HEAT CS	X	X	=
4	HEAT CS	X	X	=

7.6 ZONE LABELS

The reason for subdivision of a fire alarm system was explained earlier in the manual. The Smart Connect panel has 254 zones. The first 16 zones also have LED indications. When a fire is reported, the zone number in which the fire is located is indicated on the alphanumeric display. In addition to its numerical description, a zone can be identified by a text label, e.g. 3rd floor west ext. If the installer associates a text label with each zone of a fire alarm system, this will be displayed on the LCD when a fire is detected. The maximum length of the zone text label is 46 characters.

<p>Enter the engineer password and select the zone Icon</p> <p>Press on the zone text field. The panel displays it`s keyboard.</p>	
<p>Use <- and -> to place the cursor, and ● to delete unwanted text. Type the zone name, and press exit when done. Repeat for all required zones.</p>	





The LCD also indicates the current mode of each zone – enabled, disabled or in test mode.

7.7 ADDRESS LABELS AND ZONING DEVICES



Smart Connect is an addressable panel, i.e. it will indicate the address or location of a fire that has been detected. The address number of each point or device on the loop has already been set with the address programming tool. The installation engineer must now assign a label or location for each device, e.g. ROOM 107. A maximum of 37 characters can be used for each label. At the same time each point can be allocated to a zone.

<p>From the ENGINEER MENU, press the Devices Icon.</p> <p>Press the text field of the device to be edited</p>	
---	--

Smart Connect Single Loop Touch Screen Panel



<p>The Panel shows the on screen keyboard. Enter the required label (up to 24 characters). Press exit to return to the device list.</p>																										
<p>Press the zone field to edit the device's zone if required</p>																										
<p>Edit another device, or exit the device list to save the changes.</p>																										
<p>The Device list screen also shows the current mode of each device, i.e. ENABLED or DISABLED</p> <p>Press the MODE field of a device to toggle its state between enabled and disabled</p>	 <table border="1" data-bbox="863 1153 1388 1305"> <thead> <tr> <th>Addr</th> <th>Type</th> <th>Point text</th> <th>Mode</th> <th>Zn/Ag</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>MCP ADDR</td> <td>MAIN Entrance</td> <td>Enabled</td> <td>1</td> </tr> <tr> <td>2</td> <td>INPUT MOD</td> <td>Reception</td> <td>Disabled</td> <td>1</td> </tr> <tr> <td>3</td> <td>HEAT CS</td> <td>Admin</td> <td>Disabled</td> <td>1</td> </tr> <tr> <td>4</td> <td>HEAT CS</td> <td>Canteen</td> <td>Enabled</td> <td>1</td> </tr> </tbody> </table>	Addr	Type	Point text	Mode	Zn/Ag	1	MCP ADDR	MAIN Entrance	Enabled	1	2	INPUT MOD	Reception	Disabled	1	3	HEAT CS	Admin	Disabled	1	4	HEAT CS	Canteen	Enabled	1
Addr	Type	Point text	Mode	Zn/Ag																						
1	MCP ADDR	MAIN Entrance	Enabled	1																						
2	INPUT MOD	Reception	Disabled	1																						
3	HEAT CS	Admin	Disabled	1																						
4	HEAT CS	Canteen	Enabled	1																						
<p>The analogue values can be displayed by pressing the real time tab. Press the up & down arrows to scroll through the devices.</p>	 <table border="1" data-bbox="863 1467 1388 1608"> <thead> <tr> <th>Addr</th> <th>Type</th> <th>Point text</th> <th>Values</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>MCP ADDR</td> <td>MAIN Entrance</td> <td>V1(072) V2(000)</td> </tr> <tr> <td>2</td> <td>INPUT MOD</td> <td>Reception</td> <td>V1(072) V2(000)</td> </tr> <tr> <td>3</td> <td>HEAT CS</td> <td>Admin</td> <td>V1(000) V2(063)</td> </tr> <tr> <td>4</td> <td>HEAT CS</td> <td>Canteen</td> <td>V1(000) V2(060)</td> </tr> </tbody> </table>	Addr	Type	Point text	Values	1	MCP ADDR	MAIN Entrance	V1(072) V2(000)	2	INPUT MOD	Reception	V1(072) V2(000)	3	HEAT CS	Admin	V1(000) V2(063)	4	HEAT CS	Canteen	V1(000) V2(060)					
Addr	Type	Point text	Values																							
1	MCP ADDR	MAIN Entrance	V1(072) V2(000)																							
2	INPUT MOD	Reception	V1(072) V2(000)																							
3	HEAT CS	Admin	V1(000) V2(063)																							
4	HEAT CS	Canteen	V1(000) V2(060)																							
<p>Device specific options can be set via the options tab (See following section for details).</p> <p>Press the Options field for the required device to set its options.</p>	 <table border="1" data-bbox="863 1758 1388 1904"> <thead> <tr> <th>Addr</th> <th>Type</th> <th>Point text</th> <th>Options</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>MCP ADDR</td> <td>MAIN Entrance</td> <td>Options</td> </tr> <tr> <td>2</td> <td>INPUT MOD</td> <td>Reception</td> <td>Options</td> </tr> <tr> <td>3</td> <td>HEAT CS</td> <td>Admin</td> <td>Options</td> </tr> <tr> <td>4</td> <td>HEAT CS</td> <td>Canteen</td> <td>Options</td> </tr> </tbody> </table>	Addr	Type	Point text	Options	1	MCP ADDR	MAIN Entrance	Options	2	INPUT MOD	Reception	Options	3	HEAT CS	Admin	Options	4	HEAT CS	Canteen	Options					
Addr	Type	Point text	Options																							
1	MCP ADDR	MAIN Entrance	Options																							
2	INPUT MOD	Reception	Options																							
3	HEAT CS	Admin	Options																							
4	HEAT CS	Canteen	Options																							

Smart Connect Single Loop Touch Screen Panel





<p>The Add / Remove tab allows devices to be manually added or removed from the system. This is useful if it is not possible to perform a loop learn (eg, if a detector is to be changed to a different model, and the replacement is not available, or, if the loop is disconnected to perform maintenance / repair work)</p>	
<p>To manually remove a device, tap the device so that it is highlighted yellow, then press the delete icon </p>	
<p>To manually add a device, press the add icon </p> <p>Select the address and device type of the item being added.</p> <p>Enter the point text for the device, and select which zone it will be in.</p>	

7.8 SETTING DEVICE OPTIONS

Each Smart Connect device has a number of configuration settings that can be programmed at the panel. The configuration screen is accessed by selecting the device on the options tab. The options for each device are:-

Device	Options
<p>MCP (ZT-CP3/AD) Manual Call point</p> <p>Available options: LED flash</p>	
<p>SMOKE DETECTOR (MK-II AOP) OPTICAL SMOKE DETECTOR</p> <p>Available options: LED flash Sounder R.I. Day Setting (Off/Low/Normal/High) Night Setting (Off/Low/Normal/High)</p>	

Smart Connect Single Loop Touch Screen Panel

<p>OPTO/HEAT DETECTOR (MK-11 AOH) SMOKE and HEAT DETECTOR</p> <p>Available options: LED flash Sounder R.I. Day Setting (Off/Heat Only/Low/Normal/High) Night Setting (Off/Heat Only/Low/Normal/High)</p>	
<p>HEAT DETECTOR: FIXED HEAT Detector (MK-II AHF) ROR HEAT DETECTOR (MK-II AHR)</p> <p>Available options: LED flash Sounder R.I. Day Setting (On/Off) Night Setting (On/Off)</p>	
<p>INPUT MODULE (ZAI-MI) Addressable INPUT Module</p> <p>Available options: I/O EVENT</p>	
<p>INPUT/OUTPUT MODULE (ZAIO-MI) Addressable INPUT/OUTPUT Module</p> <p>Available options: I/O EVENT</p>	
<p>ZONE MONITOR MODULE (ZAZM-MI) Addressable ZONE MONITOR Module</p> <p>Available options: N/A</p>	<p>No Options Available. Settings are selected through PANEL Cause & Effect</p>
<p>SOUNDER CONTROL MODULE (ZASC-MI) Addressable SOUNDER CONTROL Module</p> <p>Available options: N/A</p>	<p>No Options Available. The different sound settings are selected through PANEL cause & effect.</p>
<p>Addressable SOUNDER (MK-II AMT/R) Addressable SOUNDER/FLASHER (MK-II AMTSF) Addressable SOUNDER (MK-II AMD/8R) Addressable SOUNDER (MK-II AXTR/R) Addressable SOUNDER/FLASHER (MK-II AXTSF) Addressable FLASHER (MK-II IAXTF)</p>	<p>No Options Available. The different sound and flasher settings are selected through PANEL cause & effect.</p>

8 - PROGRAMMING

8.1. CAUSE AND EFFECT.....	49
8.2 OUTPUTS AND DELAYS	53
8.2.1 SOUNDER DELAY.....	53
8.2.1 RELAY OUT DELAYS.....	53
8.2.3 PROGRAMMING DELAYS.....	53
8.2.4 SWITCHING OFF DELAYS AT ACCESS LEVEL 2.....	54
8.3 DAY / NIGHT MODE	55
8.3.1 Defining Day and Night times.....	55
8.3.2 Setting Day-time and Night-time delays.....	56
8.3.3 Setting Day-time and Night-time Detector Sensitivity	57
8.3.4 Indication of Day / Night Mode	58
8.4 USER Menu Summary.....	59
8.5 ENGINEER LEVEL Menu Summary	60
8.6 CAUSE & EFFECT SETTINGS SUMMARY	62

8.1. CAUSE AND EFFECT

The Smart Connect system has very comprehensive, but simple to use Cause and Effect capabilities.





The Default factory configuration is that any alarm will activate all outputs on the panel.

Like most addressable systems, the panel allows comprehensive programming of the sounder outputs. It is the responsibility of the commissioning engineer to verify that the programmed panel actions operate the sounders as required.

Any input (or cause) can generate any output (or effect). For example, if the input is a fire in zone 1 (e.g. an optical detector triggered by smoke), the system can be programmed to generate output(s) (e.g. operate one or more sounders or relay outputs in one or more zones).

The inputs and outputs can be selected from 4 categories – Point, Local I/O, Zone & Panel.

Example of Selecting a Cause & Effect (New Action)


<p>Press Cause/ Effect icon .</p> <p>The panel shows the default common alarm setting</p>	 <p>The screenshot shows a 'Cause/effect table' with a header row: DIR (0001) Alert + Beacon loop device (00. 01. 057) 000 000. Below it is a row: 1 / 1 Alarm on panel. The table has several empty rows below.</p>								
<p>If this is not required, tap the action so that it is highlighted yellow, then press the trash icon to delete</p>	 <p>The screenshot shows the same table as above, but the row '1 / 1 Alarm on panel' is highlighted in yellow. A trash icon is visible in the bottom navigation bar.</p>								
<p>Press the add button to add an event</p>	 <p>The screenshot shows an empty 'Cause/effect table' with the text 'No events, tap on '+' button...' in the center. A plus icon is visible in the bottom navigation bar.</p>								
<p>The panel displays the Select cause Screen, Choose the cause type (Point, Local I/O, zone or Panel). Depending on the input type chosen, the panel will display a list of sub options. For a Point alarm the options are:-</p> <table border="1" data-bbox="352 1727 580 1944"> <thead> <tr> <th>Point Cause</th> </tr> </thead> <tbody> <tr><td>Alarm + Beacon</td></tr> <tr><td>Alert + Beacon</td></tr> <tr><td>Emergency + Beacon</td></tr> <tr><td>Alarm</td></tr> <tr><td>Alert</td></tr> <tr><td>Emergency</td></tr> <tr><td>Beacon</td></tr> </tbody> </table> <p>Loop Number: Point Address:</p>	Point Cause	Alarm + Beacon	Alert + Beacon	Emergency + Beacon	Alarm	Alert	Emergency	Beacon	 <p>The screenshot shows the 'Cause/effect editor' with 'Select cause' selected. On the left, there are radio buttons for Point (selected), Local I/O, Zone, and Panel. On the right, there are input fields for 'Point causes' (set to 'Alarm'), 'Loop number' (set to '1'), and 'Point Address' (set to '1').</p>
Point Cause									
Alarm + Beacon									
Alert + Beacon									
Emergency + Beacon									
Alarm									
Alert									
Emergency									
Beacon									

Smart Connect Single Loop Touch Screen Panel

For a **Local I/O** ALARM the options are:-

Local I/O Causes	
Fault	
Alarm	
Tech Warning On	
Tech warning Off	


Local I/O start:
Local I/O end:



For a **Zone alarm**, the options are:-


Zone Causes	
Alarm	Maintenance
Detector Alarm	Tech Warning ON
MCP Alarm	Tech Warning OFF
Fault	Multi devices in alarm

Zone Start:
Zone End:



For a **Panel alarm**, the options are:-

Panel Causes	
Alarm	
Detector Alarm	
MCP Alarm	
Fault	
Maintenance	
Tech Warning ON	
Tech Warning OFF	
Multi device in alarm	
Multi Zones in Alarm	



Select whether this will be an **"AND"** cause, an **"OR"** cause, or a single **"DIRECT"** cause



An AND / OR cause will request more inputs.
Select up to 8 causes. Press OUTPUT icon when finished


AND OR	Description	000	000
	All on on panel (00) Retrigger always		
1 / 8	Alarm from alarm group (001) to (001)		
2 / 8	Alarm from alarm group (002) to (002)		
3 / 8	Alarm from alarm group (003) to (003)		
4 / 8	Alarm from alarm group (004) to (004)		
5 / 8	Alarm from alarm group (005) to (005)		
6 / 8	Alarm from alarm group (006) to (006)		
7 / 8	Alarm from alarm group (007) to (007)		
8 / 8	Alarm from alarm group (008) to (008)		

Smart Connect Single Loop Touch Screen Panel

1. After selecting the input cause(s), the panel Displays a screen to select the effect options.
2. Panel Address: Leave as zero if the output effect is on this panel, otherwise set to the network address of the destination panel.
3. Output Retrigger: this defines whether the sounders will resound from a new alarm if they had been previously silenced.

The options are:-

- **Never** resound
- Resound on an alarm from a **New zone**
- **Always** resound for any new alarm.



Select the output type (Point, Local I/O, zone or Panel)

Depending on the OUTPUT type chosen, the panel will display a list of sub options. For a point OUTPUT the options are:-


Day Delay (seconds)

Night Delay (seconds) This is the delay used if Day/Night timer is not set

Point Effects	
All On	Emergency
Alarm + Beacon	Flasher
Alert + Beacon	All Off
Emergency + Beacon	Enable
Alarm	Disable
Alert	

Loop number:

Point Address:



For a **Local I/O OUTPUT** the options are:-


Day Delay (seconds)

Night Delay (seconds)

Local I/O Effects	
Alarm	
Alert	
Sounder Off	
Enable	
Disable	

Local I/O start:

Local I/O end:



For **A. Group**, the options are:-


Day Delay (seconds)

Night Delay (seconds)

A Group Effects	
All On	Relay On
Alarm + Beacon	Relay Off
Alert + Beacon	All Off
Emergency + Beacon	Disable Sounders
Alarm	Enable Sounders
Alert	Disable Relays
Emergency	Enable Relays
Beacon	Disable Outputs
Sounder + Beacon Off	Enable Outputs

Zone Start:

Zone End:




Smart Connect Single Loop Touch Screen Panel

For a **Panel OUTPUT**, the options are:-

Day Delay (seconds)

Night Delay (seconds)

Panel Effects	
All On	Relay On
Alarm + Beacon	Relay Off
Alert + Beacon	All Off
Emergency + Beacon	Disable Sounder
Alarm	Enable Sounder
Alert	Disable Relay
Emergency	Enable Relay
Beacon	Disable Outputs
Sounder + Beacon Off	Enable Outputs



The panel shows the Programmed cause and effect.

It shows:

First row

- Event type (Direct, AND, OR), and entry number
- The programmed output.
- Day time delay
- Night time delay

Second row

- Input number & number of inputs (for And & OR statements)
- Description of input

DIR (0001)	All on on panel (00) Retrigger always	000	000
1 / 1	Alarm on panel		

The panel displays DIRECT actions with a red header, AND actions with a blue header, and OR actions with a green header.

DIR (0001)	Alarm from local device (00.3) to (00.4) Retrigger always	000	000
1 / 1	Alarm from alarm group (001) to (001)		
AND (0002)	All on on panel (00) Retrigger always	000	000
1 / 2	Alarm from alarm group (002) to (002)		
2 / 2	Alarm from alarm group (003) to (003)		
OR (0003)	All on on panel (00) Retrigger always	000	000
1 / 2	Alarm from alarm group (004) to (004)		
2 / 3	Alarm from alarm group (005) to (009)		

It is not possible to edit a programming line. If a line needs to be altered it must be deleted (tap so that it turns yellow), then the new statement entered.

DIR (0001)	Alarm from local device (00.3) to (00.4) Retrigger always	000	000
1 / 1	Alarm from alarm group (001) to (001)		
AND (0002)	All on on panel (00) Retrigger always	000	000
1 / 2	Alarm from alarm group (002) to (002)		
2 / 2	Alarm from alarm group (003) to (003)		
OR (0003)	All on on panel (00) Retrigger always	000	000
1 / 2	Alarm from alarm group (004) to (004)		
2 / 3	Alarm from alarm group (005) to (009)		


8.2 OUTPUTS AND DELAYS

Following the indication of a fire, the panel will activate outputs (i.e. sounders and / or relays) according to the cause and effect rules that have been programmed. In certain circumstances, the activation of outputs may be delayed whilst the fire is being investigated.

8.2.1 Sounder Delays

If the operation of sounders has been delayed in one or more of the programmed ACTIONS, then this will be indicated by the illumination of the DELAY ON LED (in the SOUNDER STATUS section of LEDs). When a fire has been indicated, the DELAY ON LED remains lit until the longest sounder delay has expired.

During a fire alarm it is possible to override all the sounder delays (at any access level) by pressing the delay override icon  at the bottom of the screen, as shown.



8.2.2 Relay Output Delays


Relay outputs can also be delayed via the cause and effect actions. In this case, no LED is lit to indicate a delay (since this type of output is not mandatory).

8.2.3 Programming Delays

Delays to relays and/or sounders can be programmed as part of the cause and effect programming (See previous section). If the delay will be permanently set, the delay should be entered into the NIGHT time delay field. If the delay is only to be set at certain times of the day, the panel should be configured for day/night mode. See following section

8.2.4 Switching off Delays at Access Level 2

The panel allows the delays to be turned off by the user, as this may be required as part of the normal operation of the panel.

<p>Enter the user menu in the usual way. (This option is also available in the Access level 3 Engineer menu)</p>	
<p>The panel shows Delay cancelled with Off & On options. Select ON to cancel the delay, or select OFF to keep the delay. Press Exit icon and save changes as prompted.</p>	

NOTE: As the delays can be toggled on & off via the user menu. If the delay is not working as expected, check in the user menu if the delays have been turned off.

8.3 DAY / NIGHT MODE


The Smart Connect panel has a day night timer that allows certain system responses to be altered at certain times of the day. It allows for different delays for the day and night times, and it also allows the sensitivity of certain detectors to be set differently for the day and night.

The default state of the panel is with no day/night settings programmed. It will use the “night time” delays, and the night time detector sensitivity settings.

8.3.1 Defining Day and Night times

To allow for maximum flexibility, the panel allows for more than one Day-time period each day. For example, if a site closes for a 2 hour break, the panel could be configured with 2 day-time periods eg 8:00 – 12:00 and 14:00 – 18:00.

Because of this, the panel refers to each setting as a day-time slice.

<p>Enter the engineer menu</p>																					
<p>Select the Day/Night Menu </p> <p>The panel shows that there are no daytime slices set.</p> <p>Press the add icon  to add a slice.</p>																					
<p>Select the day of the week, the start of the day slice, the end of the day slice and the operation mode:</p> <p>Operation Mode:</p> <ul style="list-style-type: none"> • MCP • MCP & Heat • MCP & Heat & Opto (Low) • MCP & Heat & Opto (Normal) • MCP & Heat & Opto (High) • Per Device Set Up <p>Press tick  to accept.</p>																					
<p>The screen shows the programmed day slice(s).</p> <p>Press the add icon  to add a slice, or press exit icon  if all slices are entered.</p>	 <table border="1" data-bbox="871 1648 1385 1823"> <thead> <tr> <th>Slice</th> <th>Day</th> <th>Start</th> <th>Stop</th> <th>Mode</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Monday</td> <td>09:00</td> <td>17:00</td> <td>MCP & HEAT & OPTO (NORMAL)</td> </tr> <tr> <td> </td> <td> </td> <td> </td> <td> </td> <td> </td> </tr> <tr> <td> </td> <td> </td> <td> </td> <td> </td> <td> </td> </tr> </tbody> </table>	Slice	Day	Start	Stop	Mode	1	Monday	09:00	17:00	MCP & HEAT & OPTO (NORMAL)										
Slice	Day	Start	Stop	Mode																	
1	Monday	09:00	17:00	MCP & HEAT & OPTO (NORMAL)																	

Smart Connect Single Loop Touch Screen Panel

<p>When there are more than 4 slices programmed, the panel displays DOWN  / UP  scroll arrows in order to view the other slices</p>	<thead> <tr> <th>Slice</th> <th>Day</th> <th>Start</th> <th>Stop</th> <th>Mode</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Monday</td> <td>09:00</td> <td>17:00</td> <td>MCP & HEAT & OPTO (NORMAL)</td> </tr> <tr> <td>2</td> <td>Tuesday</td> <td>09:00</td> <td>17:00</td> <td>MCP & HEAT & OPTO (NORMAL)</td> </tr> <tr> <td>3</td> <td>Wednesday</td> <td>09:00</td> <td>17:00</td> <td>MCP & HEAT & OPTO (NORMAL)</td> </tr> <tr> <td>4</td> <td>Thursday</td> <td>09:00</td> <td>17:00</td> <td>MCP & HEAT & OPTO (NORMAL)</td> </tr> </tbody>	Slice	Day	Start	Stop	Mode	1	Monday	09:00	17:00	MCP & HEAT & OPTO (NORMAL)	2	Tuesday	09:00	17:00	MCP & HEAT & OPTO (NORMAL)	3	Wednesday	09:00	17:00	MCP & HEAT & OPTO (NORMAL)	4	Thursday	09:00	17:00	MCP & HEAT & OPTO (NORMAL)
Slice	Day	Start	Stop	Mode																						
1	Monday	09:00	17:00	MCP & HEAT & OPTO (NORMAL)																						
2	Tuesday	09:00	17:00	MCP & HEAT & OPTO (NORMAL)																						
3	Wednesday	09:00	17:00	MCP & HEAT & OPTO (NORMAL)																						
4	Thursday	09:00	17:00	MCP & HEAT & OPTO (NORMAL)																						



| To edit a slice, tap that slice so that it is highlighted yellow, then press the delete icon . Press the add icon to add a replacement slice if required. | |
| When finished, press the exit icon . The panel will ask if you want to save the changes. Press tick to save the changes, or press to discard. | |

8.3.2 Setting Day-time and Night-time delays

The day and night time delays are set through the cause and effect programming.



<p>Enter the required cause (as described in section 8.1)</p>	
<p>When the panel asks for the output effect, enter the day time delay in the first delay field. The delay is entered in seconds. The maximum delay is 600 seconds (10 minutes).</p> <p>If no night time delay is needed, set the night time delay to Zero in the second field.</p>	

Smart Connect Single Loop Touch Screen Panel


<p>If a night time delay is needed (for example to allow security staff to investigate), a delay can be entered into the night time delay field</p>	
<p>Press tick  to save the changes. The panel shows the cause & effect table, with the daytime delay & night time delays shown in the last 2 columns.</p>	

8.3.3 Setting Day-time and Night-time Detector Sensitivity

The day and night time sensitivities are set through the Device options screen.


<p>Go to the engineer menu, and select the Devices Icon</p>																					
<p>Select the Option tab. The panel displays the Options table. Press the Options field of the device to be edited.</p> <p>Note that only the following detectors can have their sensitivity altered:-</p> <p>HEAT A1S: Heat detector OPTO STANDARD: Optical Smoke detector OPTO HEAT: Optical Smoke & Heat detector</p>	 <table border="1"> <thead> <tr> <th>Addr</th> <th>Type</th> <th>Point text</th> <th>Options</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>MCP ADDR</td> <td>MAIN Entrance</td> <td>Options</td> </tr> <tr> <td>2</td> <td>INPUT MOD</td> <td>Reception</td> <td>Options</td> </tr> <tr> <td>3</td> <td>HEAT CS</td> <td>Admin</td> <td>Options</td> </tr> <tr> <td>4</td> <td>HEAT CS</td> <td>Canteen</td> <td>Options</td> </tr> </tbody> </table>	Addr	Type	Point text	Options	1	MCP ADDR	MAIN Entrance	Options	2	INPUT MOD	Reception	Options	3	HEAT CS	Admin	Options	4	HEAT CS	Canteen	Options
Addr	Type	Point text	Options																		
1	MCP ADDR	MAIN Entrance	Options																		
2	INPUT MOD	Reception	Options																		
3	HEAT CS	Admin	Options																		
4	HEAT CS	Canteen	Options																		
<p>For the OPTO STANDARD: Optical Smoke detector, the sensitivity can be set to Off, Low, Normal or High.</p> <p>For the OPTO HEAT: Optical Smoke & Heat detector, the sensitivity can be set to Off, Heat Only, Low, Normal or High.</p> <p>There can be a different setting for day-time & night-time.</p>																					

Smart Connect Single Loop Touch Screen Panel

<p>The HEAT A1S: Heat detector and HEAT CS: Heat detector sensor can be set to Off or ON.</p>	
---	--

8.3.4 Indication of Day / Night Mode

The panel indicates its current operating mode by means of a vertical bar in the top left corner of the LCD.

<p>No Day / Night timer set. No bar in top left corner.</p>	
<p>Day / Night timer set. Panel in Day Mode. White circle in top left corner.</p>	
<p>Day / Night timer set. Panel in Night Mode. Black circle in top left corner.</p>	

8.4 USER Menu Summary

Default Password 0001 – Access level 2b



ICON	TAB SCREN	DESCRIPTON
Zones	Zone Mode	View Zone text label View / edit Zone mode "In" (Enabled/ disabled/ test/ test + sounders)
	Zone Dev	View Zone text label View Quantity of devices per zone
Devices	Basic	View Address & Device type View Device text label View / Edit device mode (Enabled / disabled) View Device Zone allocation
	Real Time	View Address & Device type View Device text label View device Analogue Values
Log	-	View Event Log
Local I/O	Input 1	View Input 1 zone allocation I/O event: (Alarm/Tech Alarm) View input 1 text label View / Edit input 1 status (Enabled / disabled)
	Input 2	View Input 2 zone allocation I/O event: (Alarm/Tech Alarm) View input 2 text label View / Edit input 2 status (Enabled / disabled)
LCD / LED	Sounder 1	View Sounder 1 zone allocation View Sounder 1 text label View / Edit Sounder 1 status (Enabled / disabled)
	Sounder 2	View Sounder 2 zone allocation View Sounder 2 text label View / Edit Sounder 2 status (Enabled / disabled)
Delays	-	Test panel LEDs , LCD & Buzzer
Alarm Group	-	Toggle panel delays on or off
	Global Mode	View / edit Relay Status (Disabled/Enabled) View / edit Sounder Status (Disabled/Enabled)
	A Group Mode	View / text label View / edit A. Grp mode (All enabled/Sounder disabled/Relay disabled/All disabled)

8.5 ENGINEER LEVEL Menu Summary

Default Password 9999 – Access Level 3



ICON	TAB SCREEN	DESCRIPTON
Loop	Automatic	Searches for all devices on the loop
	Summary	
	Detail	
Zones	Zone Mode	View / Edit Zone text label View / edit zone mode (Enabled/ disabled/ test/ test + sounders)
	Zone Dev	View Zone text label View Quantity of devices per zone
Devices	Basic	View Address & Device type View / Edit Device text label View / Edit device mode (Enabled / disabled) View / Edit Device Zone allocation
	Real Time	View Address & Device type View Device text label View device Analogue Values
	Options	View / Configure device specific options.
	Add/Remove	Add new device Remove a configured device
Log	-	View Event Log Erase event log
System	Strings	Edit Installation Name Edit installer / maintenance name Edit installer / maintenance Contact Number
	Clock	Edit Date & Time
	Language	Set Panel Language
	Users	Set Engineer text label Set engineer password Set User name label Set user password Set the number of user passwords
Cause & Effect	-	View / Enter / Delete Cause & Effect (See Section 8.1 for details)
Local I/O	Input 1	View / edit Input 1 zone allocation I/O event: (Alarm/Tech Alarm) View / edit input 1 text label View / edit input 1 status (Enabled / disabled)

Smart Connect Single Loop Touch Screen Panel

	Input 2	View / edit Input 2 zone allocation I/O event: (Alarm/Tech Alarm) View / edit input 2 text label View / edit input 2 status (Enabled / disabled)
	Sounder 1	View / edit Sounder 1 zone allocation View / edit Sounder 1 text label View / edit Sounder 1 status (Enabled / disabled)
	Sounder 2	View / edit Sounder 2 zone allocation View / edit Sounder 2 text label View / edit Sounder 2 status (Enabled / disabled)
Day / Night	-	Configure day / night timer (add Day settings)
LCD / LED	-	Test panel LEDs , LCD & Buzzer
Network	RS 485	View / edit RS485 Port status (Disabled/Enabled local/ Enabled Global) View / edit Network Node Address View / edit RS485 text label
	TCP-IP	View / edit TCP/IP Port status (Disabled/Manual/DHCP) View / edit IP Address View / edit IP DNS used View / edit IP Gateway Address View / edit IP Subnet Mask
	CLOUD	View / edit Remote access mode (Disabled/Enabled) View / edit cloud server IP address / URL View / edit IP Port used View panels MAC address
Delays	-	Toggle panel delays on or off
Alarm Group	Global Mode	View / edit Relay Status (Disabled/Enabled) View / edit Sounder Status (Disabled/Enabled)
	A Group Mode	View / text label View / edit A. Grp mode (All enabled/Sounder disabled/Relay disabled/All disabled)

8.6 CAUSE & EFFECT SETTINGS SUMMARY

The table below shows the list of options available for each type of input (cause) and Output (Effect)

Select CAUSE			
Input Type	Selection 1	Selection 2	Options
Point	Loop (1)	Address (1 - 254)	<ul style="list-style-type: none"> • Alarm • Detector Alarm • MCP Alarm • Fault • Maintenance • Tech Warning ON • Tech Warning OFF
Local I/O	Local I/O start (1-2)	Local I/O End (1-2)	<ul style="list-style-type: none"> • Fault • Alarm • Tech Warning ON • Tech Warning OFF
Zone	Zone Start (1 -254)	Zone End (1-254)	<ul style="list-style-type: none"> • Alarm • Detector Alarm • MCP Alarm • Fault • Maintenance • Tech Warning ON • Tech Warning OFF • Multi devices in alarm
Panel	-	-	<ul style="list-style-type: none"> • Alarm • Detector Alarm • MCP Alarm • Fault • Maintenance • Tech Warning ON • Tech Warning OFF • Multi devices in alarm • Multi Zones in alarm

Smart Connect Single Loop Touch Screen Panel

Select EFFECT					
Output Type	Selection 1	Selection 2	Day Delay	Night Delay	Output
Point	Loop (1)	Address (1 to 254)	(0-600)	(0-600)	<ul style="list-style-type: none"> • All On • Alarm + Beacon • Alert + Beacon • Emergency + Beacon • Alarm • Alert • Emergency • Flasher • All Off • Enable • Disable
Local I/O	Local I/O start (1-2)	Local I/O end (1-2)	(0-600)	(0-600)	<ul style="list-style-type: none"> • Alarm • Alert • Sounder Off • Enable • Disable
Zone	Zone Start (1 -254)	Zone End (1-254)	(0-600)	(0-600)	<ul style="list-style-type: none"> • All On • Alarm + Beacon • Alert + Beacon • Emergency + Beacon • Alarm • Alert • Emergency • Beacon • Sounder + Beacon Off • Relay On • Relay Off • All Off • Disable Sounders • Enable Sounders • Disable Relays • Enable Relays • Enable Output • Disable Output
Panel	-	-	(0-600)	(0-600)	<ul style="list-style-type: none"> • All On • Alarm + Beacon • Alert + Beacon • Emergency + Beacon • Alarm • Alert • Emergency • Beacon • Sounder + Beacon Off • Relay On • Relay Off • All Off • Disable Sounders • Enable Sounders • Disable Relays • Enable Relays • Enable Output • Disable Output

9 - DISABLEMENTS

9.1 DISABLEMENTS	64
9.2 ZONE DISABLEMENT	65
9.3 DEVICE DISABLEMENT	66
9.4 ALARM GROUP DISABLEMENT	68
9.4.1 Global Mode.....	68
9.4.2 Alarm Group Mode.....	70

9.1 DISABLEMENTS

To aid commissioning and assist routine maintenance checks, various functions of the Smart Connect fire alarm system can be disabled. The Smart Connect allows Disabling of Inputs in a zone, Outputs in a zone, a whole zone, or individual devices.

9.2 ZONE DISABLEMENT




When a zone is disabled, the panel will not respond to any fault or fire signals it receives from that zone.

This might be used if the system requires routine maintenance, and the user needs the rest of the system to continue running, but doesn't want spurious false alarms.



The panel will respond in the usual manner to any events in any non-disabled zones.

Any number of zones can be disabled, but it is good practice to only disable one zone at a time.

A zone can be disabled as follows:


<p>Enter the Engineer or User Password, Press the menu access icon , and select the zone icon .</p> <p>(The disabling function is available to engineer & users).</p> <p>The panel shows the Zone menu</p>	 <table border="1" data-bbox="863 817 1393 952"> <thead> <tr> <th></th> <th>Text</th> <th>In</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Basement</td> <td>Enabled</td> </tr> <tr> <td>2</td> <td>Reception</td> <td>Enabled</td> </tr> <tr> <td>3</td> <td>Office</td> <td>Enabled</td> </tr> <tr> <td>4</td> <td>Storage</td> <td>Enabled</td> </tr> </tbody> </table>		Text	In	1	Basement	Enabled	2	Reception	Enabled	3	Office	Enabled	4	Storage	Enabled			
	Text	In																	
1	Basement	Enabled																	
2	Reception	Enabled																	
3	Office	Enabled																	
4	Storage	Enabled																	
<p>For further options, press the "In" field again.</p> <p>The status changes from Output Disabled to Disabled.</p> <p>This will only disable all input devices in that zone.</p>	 <table border="1" data-bbox="863 1115 1393 1249"> <thead> <tr> <th></th> <th>Text</th> <th>In</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Basement</td> <td>Disabled</td> </tr> <tr> <td>2</td> <td>Reception</td> <td>Enabled</td> </tr> <tr> <td>3</td> <td>Office</td> <td>Enabled</td> </tr> <tr> <td>4</td> <td>Storage</td> <td>Enabled</td> </tr> </tbody> </table>		Text	In	1	Basement	Disabled	2	Reception	Enabled	3	Office	Enabled	4	Storage	Enabled			
	Text	In																	
1	Basement	Disabled																	
2	Reception	Enabled																	
3	Office	Enabled																	
4	Storage	Enabled																	
<p>When zones have been disabled, the LCD display changes from SYSTEM NORMAL to Disablement/Test. The screen shows:-</p> <p>The number of zones disabled, The number of zones with just their inputs disabled, and the total number of devices in those disabled zones.</p> <p>The General Disablement LED will be lit and also the zonal disablement LEDs will be lit for any zone with disabled inputs. The zonal disablement LEDs only apply to zones 1 to 16.</p>																			
<p>Details of the disabled zones can be viewed by pressing the disabled zones icon</p>	 <table border="1" data-bbox="863 1691 1393 1859"> <thead> <tr> <th></th> <th>Text</th> <th>In</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Basement</td> <td>Disabled</td> </tr> <tr> <td></td> <td></td> <td></td> </tr> </tbody> </table>		Text	In	1	Basement	Disabled												
	Text	In																	
1	Basement	Disabled																	

Smart Connect Single Loop Touch Screen Panel

<p>Details of the individual devices disabled can be viewed by pressing the disabled loop devices icon</p>	 <table border="1"> <thead> <tr> <th>Address</th> <th>Type</th> <th>Point text</th> <th>Mode</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>MCP ADDR</td> <td>Main Entrance</td> <td>Disabled</td> </tr> <tr> <td>2</td> <td>INPUT MOD</td> <td>Reception</td> <td>Disabled</td> </tr> <tr> <td>3</td> <td>HEAT CS</td> <td>ADMIN AREA</td> <td>Disabled</td> </tr> <tr> <td>4</td> <td>HEAT CS</td> <td>OFFICE</td> <td>Disabled</td> </tr> <tr> <td>5</td> <td>HEAT CS</td> <td>OFFICE 2</td> <td>Disabled</td> </tr> <tr> <td>6</td> <td>OPT STAND</td> <td>Stock Room</td> <td>Disabled</td> </tr> </tbody> </table>	Address	Type	Point text	Mode	1	MCP ADDR	Main Entrance	Disabled	2	INPUT MOD	Reception	Disabled	3	HEAT CS	ADMIN AREA	Disabled	4	HEAT CS	OFFICE	Disabled	5	HEAT CS	OFFICE 2	Disabled	6	OPT STAND	Stock Room	Disabled
Address	Type	Point text	Mode																										
1	MCP ADDR	Main Entrance	Disabled																										
2	INPUT MOD	Reception	Disabled																										
3	HEAT CS	ADMIN AREA	Disabled																										
4	HEAT CS	OFFICE	Disabled																										
5	HEAT CS	OFFICE 2	Disabled																										
6	OPT STAND	Stock Room	Disabled																										
<p>To re-enable a zone, use the same procedure, pressing the In field until it shows Enabled. It cycles through:-</p> <ul style="list-style-type: none"> • Enabled • Disabled • Test • Test + Sounder 	 <table border="1"> <thead> <tr> <th>Text</th> <th>In</th> </tr> </thead> <tbody> <tr> <td>1 Basement</td> <td>Enabled</td> </tr> <tr> <td>2 Reception</td> <td>Enabled</td> </tr> <tr> <td>3 Office</td> <td>Enabled</td> </tr> <tr> <td>4 Storage</td> <td>Enabled</td> </tr> </tbody> </table>	Text	In	1 Basement	Enabled	2 Reception	Enabled	3 Office	Enabled	4 Storage	Enabled																		
Text	In																												
1 Basement	Enabled																												
2 Reception	Enabled																												
3 Office	Enabled																												
4 Storage	Enabled																												

9.3 DEVICE DISABLEMENT

Rather than disable an entire zone, it is often useful to just disable one or more input devices or points (detector, call point, or interface) within a zone, especially if they are malfunctioning and likely to cause a false alarm or repeatedly indicate a fault.

<p>Enter the Engineer  or User Password , Press the menu access icon, and select the Devices icon </p> <p>(The disabling function is available to engineer & users).</p> <p>The panel shows the Point menu.</p>	 <table border="1"> <thead> <tr> <th>Addr</th> <th>Type</th> <th>Point text</th> <th>Mode</th> <th>Zn/Ag</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>MCP ADDR</td> <td>MAIN Entrance</td> <td>Enabled</td> <td>1</td> </tr> <tr> <td>2</td> <td>INPUT MOD</td> <td>Reception</td> <td>Enabled</td> <td>1</td> </tr> <tr> <td>3</td> <td>HEAT CS</td> <td>Admin</td> <td>Enabled</td> <td>1</td> </tr> <tr> <td>4</td> <td>HEAT CS</td> <td>Canteen</td> <td>Enabled</td> <td>1</td> </tr> </tbody> </table>	Addr	Type	Point text	Mode	Zn/Ag	1	MCP ADDR	MAIN Entrance	Enabled	1	2	INPUT MOD	Reception	Enabled	1	3	HEAT CS	Admin	Enabled	1	4	HEAT CS	Canteen	Enabled	1
Addr	Type	Point text	Mode	Zn/Ag																						
1	MCP ADDR	MAIN Entrance	Enabled	1																						
2	INPUT MOD	Reception	Enabled	1																						
3	HEAT CS	Admin	Enabled	1																						
4	HEAT CS	Canteen	Enabled	1																						
<p>Press on the MODE field for the device to be disabled.</p> <p>Select further devices to disable if necessary, then press Exit to save.</p>	 <table border="1"> <thead> <tr> <th>Addr</th> <th>Type</th> <th>Point text</th> <th>Mode</th> <th>Zn/Ag</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>MCP ADDR</td> <td>MAIN Entrance</td> <td>Enabled</td> <td>1</td> </tr> <tr> <td>2</td> <td>INPUT MOD</td> <td>Reception</td> <td>Enabled</td> <td>1</td> </tr> <tr> <td>3</td> <td>HEAT CS</td> <td>Admin</td> <td>Disabled</td> <td>1</td> </tr> <tr> <td>4</td> <td>HEAT CS</td> <td>Canteen</td> <td>Enabled</td> <td>1</td> </tr> </tbody> </table>	Addr	Type	Point text	Mode	Zn/Ag	1	MCP ADDR	MAIN Entrance	Enabled	1	2	INPUT MOD	Reception	Enabled	1	3	HEAT CS	Admin	Disabled	1	4	HEAT CS	Canteen	Enabled	1
Addr	Type	Point text	Mode	Zn/Ag																						
1	MCP ADDR	MAIN Entrance	Enabled	1																						
2	INPUT MOD	Reception	Enabled	1																						
3	HEAT CS	Admin	Disabled	1																						
4	HEAT CS	Canteen	Enabled	1																						
<p>When a device has been disabled, the LCD display changes from SYSTEM NORMAL to Disablement, as shown.</p> <p>The screen shows the number of devices disabled.</p> <p>The General Disablement LED will be lit, but the zonal disablement LEDs will not light, unless all devices in that zone have been disabled.</p>	 <p>1 Disablement</p> <p>1 Disabled loop devices</p>																									

Smart Connect Single Loop Touch Screen Panel

<p>Details of the individual devices disabled can be viewed by pressing the disabled loop devices icon</p>	
<p>To re-enable a device, use the same procedure, pressing the Mode field until it shows Enabled.</p>	

Once a device is disabled, the panel ignores any alarms or faults generated by the device. If all devices in a zone are disabled, the panel will indicate a zone disablement. If subsequently one or more devices are re-enabled then the zone disablement indication will be automatically cancelled.

To re-enable a disabled device, repeat the same procedure used for disabling the device, selecting Enable instead of Disable.

9.4 Alarm Group Disablement

<p>Enter the Engineer or User Password, Press the menu access icon , and select the Alarm group Icon .</p> <p>(The disabling function is available to engineer & users).</p> <p>The panel shows the Alarm Group Explorer</p>	
--	--

9.4.1 Global Mode Disablement




When Global mode is disabled, the panel will not respond to any fault or fire signals it receives from that loop.

This might be used if the system requires routine maintenance, and the user needs the rest of the system to continue running, but doesn't want spurious false alarms.






The panel will respond in the usual manner to any events in any non-disabled zones.

Global mode can be disabled, but it is good practice to only disable one alarm group at a time.



Global mode can be disabled as follows:

<p>Select the global mode for relay status to Disable by pressing the white DOT – Disabled. The status changes from enabled to All Disabled for output relay.</p> <p>This would disable all output interfaces in the loop.</p> <p>Press exit to save.</p>	
<p>The Relay status changes from All enabled to All disabled.</p> <p>This would disable all output interfaces in the loop.</p>	
<p>When relay status have been disabled, the LCD display changes from SYSTEM NORMAL to Disablement, as shown.</p> <p>The screen shows the number of output interface devices disabled.</p> <p>The General Disablement LED will be lit.</p>	

Smart Connect Single Loop Touch Screen Panel

<p>Details of the disabled output interface can be viewed by pressing the  disabled loop device icon.</p>	 <table border="1"> <thead> <tr> <th>Address</th> <th>Type</th> <th>Point text</th> <th>Mode</th> </tr> </thead> <tbody> <tr> <td>68</td> <td>MAINS I/O</td> <td>LOOP DEVICE 68</td> <td>Output disabled</td> </tr> <tr> <td>90</td> <td>IO MODUL</td> <td>LOOP DEVICE</td> <td>Output disabled</td> </tr> <tr> <td>101</td> <td>IO MODUL</td> <td>LOOP DEVICE</td> <td>Output disabled</td> </tr> <tr> <td>112</td> <td>IO MODUL</td> <td>LOOP DEVICE</td> <td>Output disabled</td> </tr> <tr> <td>123</td> <td>IO MODUL</td> <td>LOOP DEVICE</td> <td>Output disabled</td> </tr> </tbody> </table>	Address	Type	Point text	Mode	68	MAINS I/O	LOOP DEVICE 68	Output disabled	90	IO MODUL	LOOP DEVICE	Output disabled	101	IO MODUL	LOOP DEVICE	Output disabled	112	IO MODUL	LOOP DEVICE	Output disabled	123	IO MODUL	LOOP DEVICE	Output disabled				
Address	Type	Point text	Mode																										
68	MAINS I/O	LOOP DEVICE 68	Output disabled																										
90	IO MODUL	LOOP DEVICE	Output disabled																										
101	IO MODUL	LOOP DEVICE	Output disabled																										
112	IO MODUL	LOOP DEVICE	Output disabled																										
123	IO MODUL	LOOP DEVICE	Output disabled																										
<p>To re-enable the relay status by pressing the white DOT-Enabled. The Relay status changes from All disabled to All enabled. Press exit to save.</p>																													
<p>Select the global mode for sounder status to Disable by pressing the white DOT – Disabled. The status changes from All enabled to All disabled for output interface. This would disable all output sounder in the loop. Press exit to save.</p>																													
<p>When sounder status has been disabled, the LCD display changes from SYSTEM NORMAL to Disabling. The screen shows:- The number of disabled alarm groups, The number of disabled output sounder devices, The number of disabled local output sounder devices, and the total number of devices in those disabled alarm groups. The General Disabling and Sounder Disabling LED will be lit.</p>																													
<p>Details of the disabled alarm group/zone can be viewed by pressing the  disabled alarm group icon.</p>	 <table border="1"> <thead> <tr> <th></th> <th>Text</th> <th>Mode</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Basement</td> <td>Output disabled</td> </tr> <tr> <td>2</td> <td>Reception</td> <td>Output disabled</td> </tr> <tr> <td>3</td> <td>Office 1</td> <td>Output disabled</td> </tr> <tr> <td>4</td> <td>Office 2</td> <td>Output disabled</td> </tr> <tr> <td>5</td> <td>Conference room</td> <td>Output disabled</td> </tr> <tr> <td>6</td> <td>Hall</td> <td>Output disabled</td> </tr> </tbody> </table>		Text	Mode	1	Basement	Output disabled	2	Reception	Output disabled	3	Office 1	Output disabled	4	Office 2	Output disabled	5	Conference room	Output disabled	6	Hall	Output disabled							
	Text	Mode																											
1	Basement	Output disabled																											
2	Reception	Output disabled																											
3	Office 1	Output disabled																											
4	Office 2	Output disabled																											
5	Conference room	Output disabled																											
6	Hall	Output disabled																											
<p>Details of the disabled output sounder can be viewed by pressing the  disabled loop device icon.</p>	 <table border="1"> <thead> <tr> <th>Address</th> <th>Type</th> <th>Point text</th> <th>Mode</th> </tr> </thead> <tbody> <tr> <td>11</td> <td>XTRA FLAS</td> <td>LOOP DEVICE 11</td> <td>Disabled</td> </tr> <tr> <td>22</td> <td>XTRA SOU</td> <td>LOOP DEVICE 22</td> <td>Disabled</td> </tr> <tr> <td>33</td> <td>XTRA SOU</td> <td>LOOP DEVICE 33</td> <td>Disabled</td> </tr> <tr> <td>44</td> <td>XTRA SOU</td> <td>LOOP DEVICE 44</td> <td>Disabled</td> </tr> <tr> <td>55</td> <td>XTRA SOU</td> <td>LOOP DEVICE 55</td> <td>Disabled</td> </tr> <tr> <td>57</td> <td>SOUNDER</td> <td>LOOP DEVICE 57</td> <td>Disabled</td> </tr> </tbody> </table>	Address	Type	Point text	Mode	11	XTRA FLAS	LOOP DEVICE 11	Disabled	22	XTRA SOU	LOOP DEVICE 22	Disabled	33	XTRA SOU	LOOP DEVICE 33	Disabled	44	XTRA SOU	LOOP DEVICE 44	Disabled	55	XTRA SOU	LOOP DEVICE 55	Disabled	57	SOUNDER	LOOP DEVICE 57	Disabled
Address	Type	Point text	Mode																										
11	XTRA FLAS	LOOP DEVICE 11	Disabled																										
22	XTRA SOU	LOOP DEVICE 22	Disabled																										
33	XTRA SOU	LOOP DEVICE 33	Disabled																										
44	XTRA SOU	LOOP DEVICE 44	Disabled																										
55	XTRA SOU	LOOP DEVICE 55	Disabled																										
57	SOUNDER	LOOP DEVICE 57	Disabled																										

Smart Connect Single Loop Touch Screen Panel

<p>Details of the disabled local output sounder can be viewed by pressing the  Local I/O icon.</p>	
<p>To re-enable the Sounder status by pressing the white DOT-Enabled. The Sounder status changes from All disabled to All enabled.</p> <p>Press exit to save.</p>	

9.4.2 Alarm Group Mode Disablement




When Alarm group mode is disabled, the panel will not respond to any fault or fire signals it receives from that zone.

This might be used if the system requires routine maintenance, and the user needs the rest of the system to continue running, but doesn't want spurious false alarms.




The panel will respond in the usual manner to any events in any non-disabled zones.

Any number of alarm group (zones) can be disabled, but it is good practice to only disable one alarm group/zone at a time.

A alarm group (zone) can be disabled as follows:

<p>Enter the Engineer or User Password, Press the menu access icon , select the Alarm group Icon  and select the A. Grp Mode tab.</p> <p>(The disabling function is available to engineer & users).</p> <p>The panel shows the Alarm Group mode menu</p>	
<p>Select the alarm group to Disable by pressing the "Out" field. The status changes from all enabled to Sounder Disabled.</p> <p>This would disable all output sounder in that alarm group (zone).</p> <p>Select further zones in the same way, or Press exit to save.</p> <p>For further options, press the "Out" field again.</p>	
<p>The status changes from Sounder Disabled to Relay Disabled.</p> <p>This would disable all Output interfaces in that alarm group (zone).</p>	

Smart Connect Single Loop Touch Screen Panel

<p>For further options, press the “Out” field again.</p> <p>The status changes from Relay Disabled to All disabled.</p> <p>This would disable all output sounders and output interfaces in that alarm group (zone).</p>	 <table border="1" data-bbox="866 271 1385 405"> <thead> <tr> <th></th> <th>Text</th> <th>Out</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Basement</td> <td>All enabled</td> </tr> <tr> <td>2</td> <td>Reception</td> <td>All enabled</td> </tr> <tr> <td>3</td> <td>Office 1</td> <td>All enabled</td> </tr> <tr> <td>4</td> <td>Office 2</td> <td>All disabled</td> </tr> </tbody> </table>		Text	Out	1	Basement	All enabled	2	Reception	All enabled	3	Office 1	All enabled	4	Office 2	All disabled									
	Text	Out																							
1	Basement	All enabled																							
2	Reception	All enabled																							
3	Office 1	All enabled																							
4	Office 2	All disabled																							
<p>When Alarm group mode has been disabled, the LCD display changes from SYSTEM NORMAL to Disablement. The screen shows:-</p> <p>The number of alarm group (zone) disabled, The number of alarm group (zone) with just their outputs disabled, and the total number of devices in those disabled alarm group (zone).</p> <p>The General Disablement and sounder disablement LED will be lit if Sounder disabled or All disabled was selected. The General Disablement LED will be lit if only Relay disabled was selected.</p>																									
<p>Details of the disabled alarm group can be viewed by pressing the disabled alarm group icon </p>	 <table border="1" data-bbox="866 936 1385 1111"> <thead> <tr> <th>Address</th> <th>Type</th> <th>Point text</th> <th>Mode</th> </tr> </thead> <tbody> <tr> <td>22</td> <td>XTRA FLAS</td> <td>LOOP DEVICE 22</td> <td>Disabled</td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> </tr> </tbody> </table>	Address	Type	Point text	Mode	22	XTRA FLAS	LOOP DEVICE 22	Disabled																
Address	Type	Point text	Mode																						
22	XTRA FLAS	LOOP DEVICE 22	Disabled																						
<p>To re-enable a zone, use the same procedure, pressing the “Out” field until it shows Enabled. It cycles through:-</p> <ul style="list-style-type: none"> • All enabled • Sounder disabled • Relay Disabled • All Disabled <p>Press exit to save.</p>	 <table border="1" data-bbox="866 1279 1385 1431"> <thead> <tr> <th></th> <th>Text</th> <th>Out</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Basement</td> <td>All enabled</td> </tr> <tr> <td>2</td> <td>Reception</td> <td>All enabled</td> </tr> <tr> <td>3</td> <td>Office 1</td> <td>All enabled</td> </tr> <tr> <td>4</td> <td>Office 2</td> <td>All enabled</td> </tr> </tbody> </table>		Text	Out	1	Basement	All enabled	2	Reception	All enabled	3	Office 1	All enabled	4	Office 2	All enabled									
	Text	Out																							
1	Basement	All enabled																							
2	Reception	All enabled																							
3	Office 1	All enabled																							
4	Office 2	All enabled																							

10 - TEST MODE

10.1 WHY USE TEST MODE	73
10.2 TO PROGRAMME ZONE INTO TEST MODE	73

10.1 WHY USE TEST MODE




To aid commissioning and assist routine maintenance check, a non-latching ‘one man test’ facility is available. Test mode can be used either with or without sounder operation, depending on the engineer’s requirements.

When a detector, manual call point or input unit is triggered on any zone in Test, the Alarm sounders operate for approximately 10 seconds on and then switch off (If selected). The triggered device is automatically reset. The panel will display the tested device on a test alarm screen, with the event highlighted in blue. The device automatically resets from the fire condition, but the LCD indication remains until the panel is manually reset.



If the device is still in the fire condition, e.g. MCP still activated or the analogue value of a detector still above the alarm threshold, the device will be triggered again and the Alarm sounders will operate for a further 10 seconds.

Should an Alarm occur on a zone that is not programmed to test, the Fire Alarm Panel will operate as normal.

10.2 TO PROGRAMME ZONE INTO TEST MODE

<p>Enter the Engineer  or User Password , Press the menu access icon, and select the zone icon .</p> <p>(The disabling function is available to engineer & users).</p> <p>The panel shows the Zone menu</p>	 <table border="1" data-bbox="863 819 1393 949"> <thead> <tr> <th></th> <th>Text</th> <th>In</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Basement</td> <td>Enabled</td> </tr> <tr> <td>2</td> <td>Reception</td> <td>Enabled</td> </tr> <tr> <td>3</td> <td>Office</td> <td>Enabled</td> </tr> <tr> <td>4</td> <td>Storage</td> <td>Enabled</td> </tr> </tbody> </table>		Text	In	1	Basement	Enabled	2	Reception	Enabled	3	Office	Enabled	4	Storage	Enabled
	Text	In														
1	Basement	Enabled														
2	Reception	Enabled														
3	Office	Enabled														
4	Storage	Enabled														
<p>Select the zone(s) to be tested by clicking on the In Field, until it shows Test</p> <p>This will give a silent test, with no sounders operating.</p>	 <table border="1" data-bbox="863 1117 1393 1247"> <thead> <tr> <th></th> <th>Text</th> <th>In</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Basement</td> <td>Enabled</td> </tr> <tr> <td>2</td> <td>Reception</td> <td>Test</td> </tr> <tr> <td>3</td> <td>Office</td> <td>Enabled</td> </tr> <tr> <td>4</td> <td>Storage</td> <td>Enabled</td> </tr> </tbody> </table>		Text	In	1	Basement	Enabled	2	Reception	Test	3	Office	Enabled	4	Storage	Enabled
	Text	In														
1	Basement	Enabled														
2	Reception	Test														
3	Office	Enabled														
4	Storage	Enabled														
<p>If the sounders are required to operate, press the In Field again. It will show Test + Sound.</p> <p>This will operate all the sounders in that zone for approximately 10 seconds, regardless of the cause and effect programming</p>	 <table border="1" data-bbox="863 1415 1393 1545"> <thead> <tr> <th></th> <th>Text</th> <th>In</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Basement</td> <td>Enabled</td> </tr> <tr> <td>2</td> <td>Reception</td> <td>Test + Sound</td> </tr> <tr> <td>3</td> <td>Office</td> <td>Enabled</td> </tr> <tr> <td>4</td> <td>Storage</td> <td>Enabled</td> </tr> </tbody> </table>		Text	In	1	Basement	Enabled	2	Reception	Test + Sound	3	Office	Enabled	4	Storage	Enabled
	Text	In														
1	Basement	Enabled														
2	Reception	Test + Sound														
3	Office	Enabled														
4	Storage	Enabled														
<p>When all required zones have been selected, press exit and accept the change. The panel will return to the menu, showing that there is a Disablement or test condition present .</p>																

Smart Connect Single Loop Touch Screen Panel

<p>To view which zones are in test mode, press the test icon .</p>	 <table border="1"> <thead> <tr> <th></th> <th>Text</th> <th>In</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Reception</td> <td>Test = Sound</td> </tr> <tr> <td></td> <td></td> <td></td> </tr> </tbody> </table>		Text	In	1	Reception	Test = Sound												
	Text	In																	
1	Reception	Test = Sound																	
<p>Proceed to test the devices. The panel will show all test events on a separate test screen. The events will be highlighted blue to</p>	 <table border="1"> <tbody> <tr> <td>001</td> <td>20170809 12:32 -> ALARM - MCP ADDRESSABLE Point : 012 - LOOP DEVICE 12 Zone : 002 - ZONE 2</td> </tr> <tr> <td>002</td> <td>20170809 12:36 -> ALARM - OPT STANDARD Point : 013 - LOOP DEVICE 13 Zone : 002 - ZONE 2</td> </tr> </tbody> </table>	001	20170809 12:32 -> ALARM - MCP ADDRESSABLE Point : 012 - LOOP DEVICE 12 Zone : 002 - ZONE 2	002	20170809 12:36 -> ALARM - OPT STANDARD Point : 013 - LOOP DEVICE 13 Zone : 002 - ZONE 2														
001	20170809 12:32 -> ALARM - MCP ADDRESSABLE Point : 012 - LOOP DEVICE 12 Zone : 002 - ZONE 2																		
002	20170809 12:36 -> ALARM - OPT STANDARD Point : 013 - LOOP DEVICE 13 Zone : 002 - ZONE 2																		
<p>When complete, take the panel out of test mode by selecting the zone icon. Click the "In" field until it shows enabled. Press exit and save changes in order to return the panel to normal.</p>	 <table border="1"> <thead> <tr> <th></th> <th>Text</th> <th>In</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>Basement</td> <td>Enabled</td> </tr> <tr> <td>2</td> <td>Reception</td> <td>Enabled</td> </tr> <tr> <td>3</td> <td>Office</td> <td>Enabled</td> </tr> <tr> <td>4</td> <td>Storage</td> <td>Enabled</td> </tr> </tbody> </table>		Text	In	1	Basement	Enabled	2	Reception	Enabled	3	Office	Enabled	4	Storage	Enabled			
	Text	In																	
1	Basement	Enabled																	
2	Reception	Enabled																	
3	Office	Enabled																	
4	Storage	Enabled																	

11 - NETWORKING

11.1 NETWORKING	76
11.2 RING NETWORK	76
11.3 BUS NETWORK.....	76
11.4 CONFIGURING THE NETWORK	76
11.5 RUNNING THE NETWORK	77
11.6 CONFIGURING TCP/IP CONNECTION.....	77
11.7 CONFIGURING THE CLOUD SETTING.....	78

11.1 NETWORKING

The Smart Connect panel has built in network connections, so no additional hardware is needed to network panels together.

Up to 64 control panels (CIEs) can be connected together, i.e. networked. The maximum distance between nodes is 1 km using a screened data cable, or 100m using a standard fireproof cable.

The network can be configured with a ring or bus topology.



11.2 RING NETWORK

In a ring network, each control panel is connected to 2 other control panels to form a ring. This has the same topology as the loops of addressable devices connected to each CIE. This has the advantage that no panels are lost if there is a single break in the network.




11.3 BUS NETWORK

This is similar to a ring network but wired panel to panel without a return connection from last panel to first panel. It could also be referred to as a radial or spur network.

11.4 CONFIGURING THE NETWORK

<p>Enter the engineer menu</p>	
<p>Select the Network Menu , and press the RS485 tab</p> <p>The panel shows that the network connection is disabled (It's default state).</p>	
<p>Set a node address. Note that each panel on the network must have a separate address.</p> <p>Change the mode to Enabled local.</p> <p>The panel will not receive alarm and fault messages from remote panel.</p>	

Smart Connect Single Loop Touch Screen Panel

<p>Change the mode to Enabled Global.</p> <p>The panel will receive alarm and fault messages from remote panel.</p>	 <p>The screenshot shows the 'Network Setup' screen for RS485. The 'TCP/IP' tab is selected. Under the 'Mode' section, three radio buttons are visible: 'Disabled', 'Enabled local', and 'Enabled Global'. The 'Enabled Global' radio button is selected. Below the mode section, there are input fields for 'Address' (containing '1') and 'Name' (containing 'Zeta Alarm Systems'). At the bottom, there are three icons: a left arrow, a green checkmark, and a plus icon.</p>																				
<p>Repeat the above step for all panels on the network, then press the Add icon  to search and configure the network.</p>	 <p>The screenshot shows the 'Node Searching' screen. It features a large blue progress bar at the top and a white area below it, likely for displaying search results. The bottom navigation bar is the same as in the previous screenshot.</p>																				
<p>When the search is complete, the panel shows a list of network node addresses seen, and whether the panel sees a connection on Network port A (NET 1), and Network port B (NET 2).</p> <p>If the panel sees a connection it reports the port as UP. If it does not see a connection, it reports the port as down.</p> <p>(In this example we have a single panel)</p>	 <p>The screenshot shows the 'Network Report' screen with '2 Nodes' listed. A table displays the following data:</p> <table border="1" data-bbox="885 831 1369 1003"> <thead> <tr> <th></th> <th>Address</th> <th>Net 1</th> <th>Net 2</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>1</td> <td>Up</td> <td>Down</td> </tr> <tr> <td>2</td> <td>2</td> <td></td> <td>Up</td> </tr> <tr> <td>3</td> <td></td> <td></td> <td></td> </tr> <tr> <td>4</td> <td></td> <td></td> <td></td> </tr> </tbody> </table> <p>The bottom navigation bar shows a green checkmark and the plus icon.</p>		Address	Net 1	Net 2	1	1	Up	Down	2	2		Up	3				4			
	Address	Net 1	Net 2																		
1	1	Up	Down																		
2	2		Up																		
3																					
4																					

11.5 RUNNING THE NETWORK


On a Smart Connect panel, running in a network, all events are reported at all panels. All panels are able to silence & reset the system, when a suitable access code has been entered.

Operation of outputs over the network is determined by the programmed cause & effect. Any input on the network can be programmed to operate any output. The cause & effect is entered at the panel that has the INPUT CAUSE connected.


11.6 CONFIGURING TCP/IP CONNECTION

WARNING: DO NOT PLUG SMART CONNECT INTO PoE ETHERNET SOCKET. THIS WILL DAMAGE THE PANEL.

The Smart Connect panel has a TCP/IP connection that allows the panel to report events to a central server. To do this, First the TCP/IP address must be set.

<p>From the Network Menu , press the TCP/IP tab.</p> <p>The panel shows that the TCP/IP connection is disabled (It's default state).</p>	 <p>The screenshot shows the 'Network Setup' screen with the 'TCP/IP' tab selected. Under the 'Mode' section, three radio buttons are visible: 'Disabled', 'Manual', and 'DHCP'. The 'Disabled' radio button is selected. Below the mode section, there are input fields for 'IP' (192.168.002.200), 'DNS' (008.008.008.008), 'Gateway' (192.168.002.001), and 'Mask' (255.255.255.000). At the bottom, there are two icons: a left arrow and a plus icon.</p>
---	--



Smart Connect Single Loop Touch Screen Panel

<p>Select DHCP for the LAN to assign the settings, or select manual to enter the settings by hand.</p> <p>If entering the settings by hand, just type the numbers. The panel will automatically insert the dots.</p>	
--	--

With only the TCP/IP configured, the panel will sit on a network, but would need 3rd party software on a PC to do anything useful. The cloud tab will need to be configured in order for the panel to link to the remote server.

11.7 CONFIGURING THE CLOUD SETTINGS

The Smart Connect panel has been designed to report events to a central server. This will allow authorised users to view the current status of the panel. The settings are usually set at the factory, but can be configured by the installer if required.




<p>From the Network Menu , press the Cloud tab.</p> <p>Enter Server and Port details as required. Make a note of the MAC address, as this will be needed to register the panel at the server.</p>	
<p>The Mode setting determines whether remote access to the panel is enabled or disabled.</p> <p>To allow an engineer to interrogate the panel remotely, this should be set to enabled. This is to prevent access to a panel without a responsible person physically at the fire panel.</p> <p>These settings will time out after a short period of inactivity.</p>	

12 - FAULT FINDING

12.1 LOOP WIRING FAULT FINDING	80
12.2 LOOP CONTENTS FAULT FINDING	81
12.3 ZONE FAULTS.....	81
12.4 POWER SUPPLY FAULTS.....	82
12.5 EARTH FAULTS	83
12.6 SYSTEM FAULT	84
12.7 PANEL INPUT AND CONVENTIONAL SOUNDER FAULTS.....	85
12.8 EVENT LOGS.....	86


12.1 LOOP WIRING FAULT FINDING

The Smart Connect panel will monitor the addressable loop for open or short circuit faults. The panel's Loop Isolator monitors for both Open and short circuit faults, to the faults are reported as ISOLATOR FAULTS, with a Description. The faults reported are:-

<p>Break in -ve wire</p>		<p>To locate a cable break, re-run the loop search, and check the detailed loop report after the search is complete.</p>  <table border="1" data-bbox="906 533 1441 667"> <thead> <tr> <th>Address</th> <th>Type</th> <th>Side A</th> <th>Side B</th> <th>dBase</th> </tr> </thead> <tbody> <tr> <td>153</td> <td>MCP ADDRESSABLE</td> <td>X</td> <td></td> <td>=</td> </tr> <tr> <td>154</td> <td>INPUT MODULE</td> <td>X</td> <td></td> <td>=</td> </tr> <tr> <td>155</td> <td>HEAT CS</td> <td></td> <td>X</td> <td>=</td> </tr> <tr> <td>156</td> <td>HEAT CS</td> <td></td> <td>X</td> <td>=</td> </tr> </tbody> </table>	Address	Type	Side A	Side B	dBase	153	MCP ADDRESSABLE	X		=	154	INPUT MODULE	X		=	155	HEAT CS		X	=	156	HEAT CS		X	=
Address	Type	Side A	Side B	dBase																							
153	MCP ADDRESSABLE	X		=																							
154	INPUT MODULE	X		=																							
155	HEAT CS		X	=																							
156	HEAT CS		X	=																							
<p>Break in +ve wire</p>		<p>Use the same method to locate a break. In the example above, the break is between address 150 (which is seen from side A only), and address 152 (which is seen from side B only)</p> <p>(This applies if the loop is addressed sequentially)</p>																									


<p>Short circuit on side A of the loop</p>		<p>If the panel reports a loop short side A , then there is a short circuit fault on the loop, somewhere between the panel (side A), and the first device with a short circuit isolator on the loop.</p>
<p>Short circuit on side B of the loop</p>		<p>If the panel reports a loop short side B , then there is a short circuit fault on the loop, somewhere between the panel (side B), and the last device with a short circuit isolator on the loop.</p>

Smart Connect Single Loop Touch Screen Panel

<p>A short circuit in the middle of the loop, will usually cause two loop short circuit isolators to activate, and will cause the devices between the isolators to go missing (as they are no longer powered).</p>		<p>The short circuit will be somewhere between the 2 operated SC isolators. Check which addresses are missing.</p>
--	---	--

12.2 LOOP CONTENTS FAULT FINDING

If the loop contents are different to what was expected, then there two probable causes:




<p>Two or more devices may have the same address setting. This is referred to as a DOUBLE ADDRESS FAULT. If this occurs all devices with the same address will answer at the same time. The panel will not be able to understand the answer it receives</p>	 <table border="1" data-bbox="399 862 970 996"> <thead> <tr> <th>Address Type</th> <th>Side A</th> <th>Side B</th> <th>dBase</th> </tr> </thead> <tbody> <tr> <td>1 MCP ADDRESSABLE</td> <td>X</td> <td>X</td> <td>=</td> </tr> <tr> <td>2 INPUT MODULE</td> <td>X</td> <td>X</td> <td>=</td> </tr> <tr> <td>3 Double address</td> <td>X</td> <td>X</td> <td>!!</td> </tr> <tr> <td>4 HEAT CS</td> <td>X</td> <td>X</td> <td>=</td> </tr> </tbody> </table>	Address Type	Side A	Side B	dBase	1 MCP ADDRESSABLE	X	X	=	2 INPUT MODULE	X	X	=	3 Double address	X	X	!!	4 HEAT CS	X	X	=	<p>Search the detailed loop report for double addresses.</p> <p>Look for missing addresses in the detailed summary. Missing numbers are likely to be the double addressed ones.</p> <p>Try removing the known device & relearn the loop. If just 2 devices were at that address, the other device will now be seen, and the panel will report it's type, which may help reduce the search</p>
Address Type	Side A	Side B	dBase																			
1 MCP ADDRESSABLE	X	X	=																			
2 INPUT MODULE	X	X	=																			
3 Double address	X	X	!!																			
4 HEAT CS	X	X	=																			
<p>Cable break</p>		<p>If a system is only wired as a loop, any breaks will be reported, and can be located as described in the previous section.</p> <p>If a system uses spurs, a cable break in the spur will not be seen. Look for missing device addresses in the loop report.</p>																				
<p>Reverse Polarity Devices</p>		<p>Some devices are polarity sensitive, so will not be seen if + & - connections are reversed.</p> <p>Look for missing devices in the loop report, and check their</p>																				

12.3 ZONE FAULTS


There are several reasons for the zone fault LED to light.

<p>A device has been removed from that zone.</p>		
--	---	--


Smart Connect Single Loop Touch Screen Panel

<p>A device has been changed for one of a different type</p>		
<p>There is a Double Address in this zone (see previous section)</p>		
<p>A device in that zone is communicating a fault condition to the panel.</p>		<p>The fault message indicates whether the interface has detected an open or short circuit fault on its field wiring, or if it has lost its auxiliary power supply input</p>

12.4 POWER SUPPLY FAULTS

<p>Mains Supply Fault</p>		<p>Check If Mains Power is present</p> <p>Check if there is voltage out of the PSU cage (29.5V DC)</p>
<p>Battery Removed</p>		<p>Check battery fuse.</p> <p>Check that battery connections are secure.</p> <p>Check battery voltage (should be around 26-27V for well charged batteries).</p> <p>Check that the two batteries are connected in SERIES (to give double the voltage of 1 battery on its own).</p> <p>Check the charger fuse.</p>



Smart Connect Single Loop Touch Screen Panel

<p>Charger Fault</p>		<p>The panel has determined that the power supply is not charging the batteries.</p> <p>This is likely to be a problem with the Charger PCB. Contact your supplier to arrange a replacement charger PCB</p>
<p>Battery high impedance fault</p>		<p>The panel has measured the battery internal resistance and has determined it is too high.</p> <p>The batteries will need to be replaced.</p>

12.5 EARTH FAULTS

An EARTH fault indicates that something is shorting to earth (usually through the cable screen). Disconnect the earth screens one at a time to determine the problem line. (Note: connecting other equipment, e.g. a mains powered laptop, to the panel can give an earth fault)

The earth fault message will indicate if it is a Positive or Negative voltage shorting to earth.

<p>Earth Positive Fault</p>		<p>Most Earth faults occur on the Addressable loop. As a first check disconnect all the loop connections, and reset the panel. If no earth fault is reported the fault is on the loop. Locate the fault by splitting the loop in half, connecting one side of the loop at a time, then sub dividing the "bad section". Look for the cable screen shorting to loop +</p> <p>If the fault is not on the loop, use a similar method to investigate all other circuits.</p>
<p>Earth Negative Fault</p>		<p>Use the same method , but look for shorts to loop -ve</p>




Note that for the on board conventional sounder circuits, in the off condition, both sounder + and sounder – terminals are POSITIVE with respect to earth, so a short circuit to either would give a positive earth fault.

*****DO NOT DISCONNECT THE MAINS EARTH CONNECTION. THIS WILL CAUSE A PROBLEM WITH THE PANELS OPERATION*****





12.6 SYSTEM FAULT

A system fault is an abnormal microprocessor running condition due to various unexpected phenomena.

This will result in the panel attempting to correct itself. Should this fault occur, the System Fault LED, General Fault LED, General Fault relay and internal fault buzzer will be constantly active. A system fault indication can be cleared by pressing the system fault reset button located underneath the PCB. If the fault does not clear please consult your distributor.






<p>Location of System Fault Reset Button from front of the panel</p>	 A photograph of the front of the Smart Connect panel. The panel is grey with a blue touch screen. At the top, there are terminals labeled 'C NC RELAY', '+S1-', '+S2-', and 'ETHERNET CONNECTOR'. Below the terminals, the text 'SMART CONNECT' is printed in a stylized font, followed by 'ADDRESSABLE FIRE ALARM PANEL' and 'EN54-2 & EN54-4'. A yellow circle highlights a small, round, white button located on the right side of the panel, below the 'SMART CONNECT' logo.
<p>Viewed from side of the panel</p>	 A photograph showing the side of the panel. The panel is white. A yellow circle highlights a small, round, white button located on the side of the panel, near the bottom.
<p>Viewed from the rear of the PCB</p>	 A photograph of the rear of the PCB. The PCB is green. A yellow circle highlights a small, round, white button located on the PCB, near the bottom left corner.

12.7 PANEL INPUT AND CONVENTIONAL SOUNDER FAULTS

<p>LOCAL INPUT OPEN</p>		<p>Check the local input has an EOL resistor fitted</p> <p>Check that the EOL resistor is the correct value (4.7 kΩ)</p> <p>Check that there are no cable breaks or loose connections</p>
<p>LOCAL INPUT SHORTED</p>		<p>Check that there are no cable short circuits on the circuits.</p> <p>Check that the EOL resistor is the correct value (4.7 kΩ)</p> <p>Check that there are no Normally closed switches connected to this circuit.</p>
<p>LOCAL OUTPUT OPEN</p>		<p>Check the local Output (Sounder Circuit) has an EOL resistor fitted</p> <p>Check that the EOL resistor is the correct value (4.7 kΩ)</p> <p>Check that there are no cable breaks or loose connections</p>
<p>LOCAL OUTPUT SHORTED</p>		<p>Check that there are no cable short circuits on the circuits.</p> <p>Check that there are no non-polarised devices connected to the circuit.</p>

12.8 EVENT LOGS

The Smart Connect event log which has a capacity of 8032 events. It stores all faults & alarms that occur on the system.

<p>Faults are reported with a YELLOW Highlight.</p> <p>The highlighted part gives the time & date and the general fault information.</p> <p>The table shows more detail of the fault</p> <p>The left hand column shows the event number.</p>	 <p>The screenshot shows a 'Log file' window with a list of events. Three entries are highlighted in yellow:</p> <ul style="list-style-type: none"> 004: 2017/08/22 12:30 --> DEVICE NOT RESPONDING - HEAT A1S (Point: 136 - LOOP DEVICE 136, Zone: 006 - ZONE 6) 005: 2017/08/22 12:30 --> DEVICE NOT RESPONDING - HEAT A1S (Point: 137 - LOOP DEVICE 137, Zone: 006 - ZONE 6) 006: 2017/08/22 12:30 --> DEVICE NOT RESPONDING - HEAT A1S (Point: 138 - LOOP DEVICE 138, Zone: 006 - ZONE 6)
<p>Operational event are reported with a MAGENTA Highlight.</p> <p>The highlighted part gives the time & date and the operation information.</p> <p>The table shows more detail of the operation.</p> <p>The left hand column shows the event number.</p>	 <p>The screenshot shows a 'Log file' window with three magenta-highlighted entries:</p> <ul style="list-style-type: none"> 044: 2017/08/22 14:30 --> BUTTON PRESSED (User: 1, Origin: local panel, Action:) 045: 2017/08/22 14:34 --> BUTTON PRESSED (User: 1, Origin: local panel, Action:) 046: 2017/08/22 14:38 --> POWER ON
<p>Alarms are reported with a RED Highlight.</p> <p>The highlighted part gives the time & date and the Type of detector signalling alarm</p> <p>The table shows more detail of the Alarm (Address, Device text label, zone, zone text label)</p> <p>The left hand column shows the event number.</p>	 <p>The screenshot shows a 'Log file' window with three red-highlighted entries:</p> <ul style="list-style-type: none"> 133: 2017/08/22 15:30 --> ALARM - HEAT A1S (Point: 006 - LOOP DEVICE 6, Zone: 001 - ZONE 1) 134: 2017/08/22 15:31 --> ALARM - HEAT A1S (Point: 043 - LOOP DEVICE 43, Zone: 001 - ZONE 1) 135: 2017/08/22 15:33 --> ALARM - HEAT A1S (Point: 053 - LOOP DEVICE 53, Zone: 001 - ZONE 1)
<p>Test events are reported with a GREEN Highlight.</p> <p>The highlighted part gives the time & date and the Type of detector signalling alarm</p> <p>The table shows more detail of the Alarm (Address, Device text label, zone, zone text label)</p> <p>The left hand column shows the event number.</p>	 <p>The screenshot shows a 'Log file' window with three green-highlighted entries:</p> <ul style="list-style-type: none"> 077: 2017/08/22 16:17 --> ALARM - HEAT A1S (Point: 072 - LOOP DEVICE 72, Zone: 003 - ZONE 3) 078: 2017/08/22 16:17 --> DEVICE NOT RESPONDING - HEAT A1S (Point: 074 - LOOP DEVICE 74, Zone: 003 - ZONE 3) 079: 2017/08/22 16:19 --> DEVICE NOT RESPONDING - HEAT A1S (Point: 075 - LOOP DEVICE 75, Zone: 003 - ZONE 3)
<p>When viewing the event log from the engineer menu, there is an option to erase the event log by pressing the  delete icon.</p> <p>The panel will ask to confirm this action. Press tick to delete, or cancel to leave the log in the panel.</p> <p>When viewed from the user menu, there is no delete option.</p>	 <p>The screenshot shows a confirmation dialog box with the text 'Confirm the changes?'. It has two buttons: a red 'X' button (cancel) and a green checkmark button (confirm).</p>

13 - STANDBY BATTERY REQUIREMENTS

13.1 STANDBY BATTERY REQUIREMENTS	88
13.2 DEVICE CURRENT RATINGS.....	88
13.3 DEVICE COMPATIBILITY CHART.....	89
13.4 STANDBY BATTERY CALCULATION.....	90

13.1 STANDBY BATTERY REQUIREMENTS

It is the responsibility of the system designer to choose batteries that will give the required system standby time. The following pages give the information needed to help determine the minimum battery requirements.

13.2 DEVICE CURRENT RATINGS

The Following Table shows the Quiescent, Alarm currents of the main parts of a Smart Connect Fire Alarm System:

DEVICE	QUIESCENT	ALARM
MKII-AOP	0.5	5
MKII-AOH	0.5	5
MKII-AHR	0.5	5
MKII-AHF	0.5	5
ZT-CP3/AD	0.45	2.3
ZT-CP3/AD/WP	0.45	2.3
MKII-AXT/x	0.65	4.5
MKII-AXTB/x	2.3	20.3
MKII-SSB	0.65	5.5
ZRAP/x	2.3	6.4
ZRAPB/x	2.3	20.3
ZAI-MI	1	3.6
ZAIO-MI	1	2
ZASC-MI	0.6	0.8
ZAZM-MI	3.5	13.2
ZAIOI/230	1.5	4.6
SMM/B	1.1	12
Wi-Fyre Transponder	12	12
MKII-CB	n/a	n/a
MKII-CB/D	n/a	n/a
MKII-IB	0.05	7
MKII-ARL/x	0.5	5

The Maximum per loop values given above are a guideline, based on the assumption that other devices on the loop do not cause the total loop current to exceed the loop limit of 500mA. Current readings may change in future updates.

*AXTB, ZRAP & ZRAPB Dip settings: 1000, current varies per switch settings.

13.3 Device Compatibility Chart

	Repeater Panels	Addressable Detectors	Addressable Sounders	Addressable Interfaces	Detector Bases	Remote LED's
Simplicity 64	SP-REP QT-REP ID2/REP DATALOG	MKII-AOP MKII-AOH MKII-AHR MKII-AHF ZT-CP3/AD ZT-CP3/AD/WP	*MKII-AXT/x *MKII-AXTB/x *MKII-ZRAP *MKII-ZRAPB MKII-SSB	ZAI-MI ZAI-MI ZAS-C-MI ZAZ-M-MI ZAIQ/230 SMM/B Wi-Fyre Transponder	MKII-CB MKII-CB/D MKII-IB	MKII-RL/W MKII-RL/C MKII-RL/W MKII-RL/C
Max per Loop	-	64	64	64	64	32
Simplicity 126	SP-REP QT-REP ID2/REP	MKII-AOP MKII-AOH MKII-AHR MKII-AHF ZT-CP3/AD ZT-CP3/AD/WP	*MKII-AXT/x *MKII-AXTB/x *MKII-ZRAP *MKII-ZRAPB MKII-SSB	ZAI-MI ZAI-MI ZAS-C-MI ZAZ-M-MI ZAIQ/230 SMM/B Wi-Fyre Transponder	MKII-CB MKII-CB/D MKII-IB	MKII-RL/W MKII-RL/C MKII-RL/W MKII-RL/C
Max Per Loop	-	126	126	64	126	32
Simplicity 252	SP-REP QT-REP ID2/REP	MKII-AOP MKII-AOH MKII-AHR MKII-AHF ZT-CP3/AD ZT-CP3/AD/WP	*MKII-AXT/x *MKII-AXTB/x *MKII-ZRAP *MKII-ZRAPB MKII-SSB	ZAI-MI ZAI-MI ZAS-C-MI ZAZ-M-MI ZAIQ/230 SMM/B Wi-Fyre Transponder	MKII-CB MKII-CB/D MKII-IB	MKII-RL/W MKII-RL/C MKII-RL/W MKII-RL/C
Max Per Loop	-	126	126	64	126	32
Premier Quatro	SP-REP QT-REP ID2/REP	MKII-AOP MKII-AOH MKII-AHR MKII-AHF ZT-CP3/AD ZT-CP3/AD/WP	*MKII-AXT/x *MKII-AXTB/x *MKII-ZRAP *MKII-ZRAPB MKII-SSB	ZAI-MI ZAI-MI ZAS-C-MI ZAZ-M-MI ZAIQ/230 SMM/B Wi-Fyre Transponder	MKII-CB MKII-CB/D MKII-IB	MKII-RL/W MKII-RL/C MKII-RL/W MKII-RL/C
Max Per Loop	-	250	250	64	250	32
Smart Loop	SP-REP QT-REP ID2/REP	MKII-AOP MKII-AOH MKII-AHR MKII-AHF ZT-CP3/AD ZT-CP3/AD/WP	*MKII-AXT/x *MKII-AXTB/x *MKII-ZRAP *MKII-ZRAPB MKII-SSB	ZAI-MI ZAI-MI ZAS-C-MI ZAZ-M-MI ZAIQ/230 SMM/B Wi-Fyre Transponder	MKII-CB MKII-CB/D MKII-IB	MKII-RL/W MKII-RL/C MKII-RL/W MKII-RL/C
Max Per Loop	-	250	250	64	250	32
Infinity ID2/2	SP-REP QT-REP ID2/REP	MKII-AOP MKII-AOH MKII-AHR MKII-AHF ZT-CP3/AD ZT-CP3/AD/WP	*MKII-AXT/x *MKII-AXTB/x *MKII-ZRAP *MKII-ZRAPB MKII-SSB	ZAI-MI ZAI-MI ZAS-C-MI ZAZ-M-MI ZAIQ/230 SMM/B Wi-Fyre Transponder	MKII-CB MKII-CB/D MKII-IB	MKII-RL/W MKII-RL/C MKII-RL/W MKII-RL/C
Max Per Loop	-	30	30	30	30	30
Infinity ID2/4	SP-REP QT-REP ID2/REP	MKII-AOP MKII-AOH MKII-AHR MKII-AHF ZT-CP3/AD ZT-CP3/AD/WP	*MKII-AXT/x *MKII-AXTB/x *MKII-ZRAP *MKII-ZRAPB MKII-SSB	ZAI-MI ZAI-MI ZAS-C-MI ZAZ-M-MI ZAIQ/230 SMM/B Wi-Fyre Transponder	MKII-CB MKII-CB/D MKII-IB	MKII-RL/W MKII-RL/C MKII-RL/W MKII-RL/C
Max Per Loop	-	60	60	60	60	32
Infinity ID2/8	SP-REP QT-REP ID2/REP	MKII-AOP MKII-AOH MKII-AHR MKII-AHF ZT-CP3/AD ZT-CP3/AD/WP	*MKII-AXT/x *MKII-AXTB/x *MKII-ZRAP *MKII-ZRAPB MKII-SSB	ZAI-MI ZAI-MI ZAS-C-MI ZAZ-M-MI ZAIQ/230 SMM/B Wi-Fyre Transponder	MKII-CB MKII-CB/D MKII-IB	MKII-RL/W MKII-RL/C MKII-RL/W MKII-RL/C
Max Per Loop	-	120	120	64	120	32

*AXTB, ZRAP & ZRAPB Dip settings: 1000, current varies per switch settings. Current readings may change in future updates.

13.4 STANDBY BATTERY CALCULATION

In order to calculate the standby battery size required, the following formula can be used:-

$$\text{Battery Size (Standby time in Amp Hours)} = 1.25 \times [(T_{\text{ALM}} \times I_{\text{ALM}}) + (T_{\text{SBY}} \times (I_{\text{QP}} + I_{\text{QL}}))]$$

Where:

T_{ALM} = Maximum time in hours required for the alarm [$\frac{1}{2}$ hour is most common time]

I_{ALM} = Total Alarm Current in amps

$I_{\text{ALM-SND}}$ = Alarm Current of Sounders in amps

T_{SBY} = Standby time in hours for the system after mains failure [normally 24, 48 or 72 hr]

I_{QP} = Quiescent current in amps of control panel in fault condition [because of mains failure]

I_{AP} = Alarm current in amps of control panel

I_{QL} = Quiescent current in amps of all loop devices.

Typical Example:

A system comprises of a 1 Loop Smart Connect panel, with 80 Addressable Optical Smoke Detectors, 15 Addressable Manual Call Points, 20 Sounders and the required standby is 24 hours. It will need to operate in alarm for $\frac{1}{2}$ hour.

Calculate the battery size required.

$$T_{\text{ALM}} = 0.5 \text{ Hr}$$

$$I_{\text{ALM-SND}} = 20 \times 0.004 = 0.08\text{A}$$

$$T_{\text{SBY}} = 24 \text{ Hr}$$

$$I_{\text{QP}} = 0.20\text{A}$$

$$I_{\text{AP}} = 0.19\text{A}$$

$$I_{\text{QL}} = 80 \times 0.00044 + 15 \times 0.001 + 20 \times 0.0005 = 0.0602\text{A}$$

$$I_{\text{ALM}} = I_{\text{ALM-SND}} + I_{\text{AP}} + I_{\text{QL}} = 0.08 + 0.19 + 0.0602 = 0.3302$$

Therefore using the equation:

$$\text{Battery Size (Standby time in Amp Hours)} = 1.25 \times [(T_{\text{ALM}} \times I_{\text{ALM}}) + (T_{\text{SBY}} \times (I_{\text{QP}} + I_{\text{QL}}))]$$

$$\text{Battery Size (Standby time in Amp Hours)} = 1.25 \times [(0.5 \times 0.33) + (24 \times (0.20 + 0.06))]$$

$$\text{Battery Size (Standby time in Amp Hours)} = 1.25 \times [(0.5 \times 0.33) + (24 \times 0.26)]$$

$$\text{Battery Size (Standby time in Amp Hours)} = 1.25 \times [0.165 + 6.24]$$

$$\text{Battery Size (Standby time in Amp Hours)} = 1.25 \times 6.405$$

$$\text{Battery Size (Standby time in Amp Hours)} = 8.01 \text{ Amp Hours}$$

For a system like this, 2 x 12V sealed lead acid batteries must be used each with a capacity greater than 8.01 Ah. For example, 12Ah

14 - CE INFORMATION

 2797	 0086
<p>Zeta Alarms Limited. 72-78 Morfa Rd, Swansea SA1 2EN</p> <p>21 23</p> <p>CPR Certificate: 2797-CPR-670814 UKCA Certificate: 2797 -CPR-780432</p>	
<p>EN54-2:1997+A1:2002 + A2: 2006 EN54-4:1997+A1:2002 + A2: 2006</p> <p>Control and indicating equipment for fire detection and fire alarm systems for buildings</p> <p>Zeta Smart Connect</p> <p>Provided options:</p> <ul style="list-style-type: none">Output to fire alarm devicesDelays to outputsDependancies (Type C)Fault signals from pointsDisablement of addressable pointsTest condition <p>Other Technical Data: See Doc: " Smart Connect Product file" held by the manufacturer</p>	